KOBE PROFESSIONAL AIR TOOLS

THE ENVIRONMENT

Always dispose of unwanted tools, accessories and packaging materials in an environmentally friendly manner.

DECLARATION OF CONFORMITY

We hereby certify that the KOBE AG7323 7"ANGLE GRINDER

(ORDER CODE: KBE-270-5323V)

Complies with all the relevant provisions of the

Machinery Directive: 2006/42/ EC

Standards Applied:

IS011148-7:2012, IS028927-1:2019

Signed:

Date: 26th March 2024

Name: Kevin Leak

Position: Quality Manager

KOBE TOOLS
Cromwell Group (Holdings) Limited.
65 Chartwell Drive, Wigston, Leicestershire,
England, LE18 2FS
Contact Us: contactus@cromwell.co.uk
Country of Origin :Taiwan

CE UKCA

QUALITY GUARANTEE & WARRANTY

KOBE INDUSTRIAL AIR TOOLS carry a one year manufacturer's warranty.

KOBE INDUSTRIAL AIR TOOLS are designed & manufactured to the highest standards & specifications
Assuring the quality and performance required by all sectors of industry.

KOBE INDUSTRIAL AIR TOOLS are fully guaranteed against faulty materials & workmanship.
Should they be found to be defective, they will either be repaired or replaced free of charge (fair wear and tear and/or misuse excepted).

Please retain supplier invoice as proof of purchase.

Cromwell Group (Holdings) Limited.
65 Chartwell Drive, Wigston, Leicestershire, England, LE18 2FS

© The Kennedy Group Ltd. 11/21

KOBE™
PROFESSIONAL AIR TOOLS

175mm (7") HEAVY DUTY ANGLE GRINDER

MODEL:
AG7323

ORDER CODE:
KBE-270-5323V

- Spindle lock design
- Spindle lock allows quick and easy disc change
- Push button lock off lever
- Rubber comfort grip
- Front exhaust



CE UKCA

WARNING: THE SAFETY INFORMATION GIVEN INSIDE MUST BE READ AND UNDERSTOOD BY ANY PERSON USING, INSTALLING, REPAIRING OR MAINTAINING THIS PRODUCT.

OPERATOR'S MANUAL

Please retain this information for future reference.

SAFETY INSTRUCTIONS

You have purchased a quality product that is designed for high performance and long service life. If correct use, safety and maintenance procedures are observed this product will last for many years.

KOBE PROFESSIONAL AIR TOOLS have been specifically designed to help you work **SAFELY** and **EFFICIENTLY**. Your care and good judgement are the best protection against injury, but always ensure that the appropriate safety equipment is worn. All possible hazards cannot be covered here, but the most important ones have been highlighted.

- Always adhere to the processes and safety warnings, which are stated in the instruction manual.

GENERAL OPERATING HAZARDS

- Never allow routine to lead to mistakes.
- Never operate if any parts are missing or damaged.
- Never allow untrained persons to operate the tool.
- Use support handle or other method to secure and support the workpiece to a stable platform.
- When using a tool that is designed to have a guard, the guard must be in place to provide protection from flying debris, grinding residue or sparks.
- Do not force the tool. Using the correct tool which is specifically designed for a select job will provide better tool performance and make the job easier.
- Disconnect the air supply before making any adjustments, changing accessories, or storing the tool. Always disconnect the air supply before performing any inspection, maintenance or tool cleaning.
- Only use accessories recommended by the manufacturer.
- Do not leave the tool unattended when it is connected to an air supply.
- Use compressed air only.

WORKPLACE HAZARDS

- Always ensure your working area is clean and well lit.
- Do not operate in explosive atmosphere, for instance extreme dust, gases and liquids.
- Keep children and bystanders away while operating the tool. Distractions can cause you to lose control.
- Never run the tool in areas exposed to water or in damp conditions.

PERSONAL PROTECTION

- Always wear approved eye protection during operation. Use safety glasses or goggles which conform to BSEN136 or CE equivalent that provide protection from the front and side. The operator of the power tool is responsible for following accepted eye, face, respiratory, hearing and body protection.
- Always ensure that all long hair and loose clothing, ties, scarves, jewellery, etc., are secured or removed.
- Always consult a doctor if numbness, tingling, pain or whitening of the skin occurs. Repetitive work motions, awkward positions and exposure to vibration can cause “Repetitive Strain Injuries”.
- Do not overreach. Keep a proper balance and footing at all times.
- Do not use the tool if under the influence of alcohol, drugs or medication.
- High sound levels can cause permanent hearing loss. Always use hearing protection whilst using the tool.


SPECIFIC SAFETY INSTRUCTIONS

- Disconnect the tool before performing service or when not in use.
- Slips, trips and falls are a major cause of serious injury or death. Be aware of excess hose left on the work floor.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the tool or these instructions to operate the tool. Power tools are dangerous in the hands of untrained users.

PARTS BREAKDOWN

CROMWELL CODE	DESCRIPTION	QTY
KBE2704367P	REPAIR KIT FOR KBE2705323V INCLUDE PARTS #10 SCREW, #16 ROTOR BLADE(4), #23 GASKET, #31 O-RING, #32 O-RING, #39 O-RING #41 SPRING, #42 O-RING	1
KBE2704844R	REBUILD FOR KBE2705323V INCLUDE PARTS #12 GEAR SHAFT(5/8-11UNC), #25 BEVEL GEAR, #27 SHAFT, #37 BALL BEARING, #47 BALL BEARING	1

PARTS BREAKDOWN




SPECIFICATIONS

ORDER CODE:	KBE-270-5323V
MODEL:	AG7323
FREE SPEED:	8,500RPM
GRINDING DISC SIZE:	175mm
AIR INLET THREAD:	¼" NPT
AIR HOSE SIZE (ID):	10mm
AIR PRESSURE:	90PSI (6.2bar)
AIR CONSUMPTION:	44.2CFM(free speed), 43.6CFM(at load)
OVERALL LENGTH:	350mm
WEIGHT:	3.5kg

SUGGESTED AIR SUPPLY

WARNING! BEFORE ATTEMPTING TO ASSEMBLE THIS PRODUCT, MAKE SURE YOU ARE FAMILIAR WITH ALL SAFETY INSTRUCTIONS.



1. For optimal results you should incorporate a regulator, lubricator and an inline filter.
2. If you are not using an automatic lubricating system, before operating the tool, add a few drops of pneumatic tool oil to the air-line connection. Add more after each hour of constant using.
3. Do not exceed maximum air pressure of 90PSI/ 6.2bar.

PLEASE NOTE: Use compressed air only.

OPERATION

WARNING! BEFORE ATTEMPTING TO USE THIS PRODUCT, MAKE SURE YOU ARE FAMILIAR WITH ALL OPERATING AND SAFETY INSTRUCTIONS.

Check the position of the reversing mechanism before operating the tool so as to be aware of the direction of rotation when operating. Before using an angle grinder, during use or installing a new grinding/cutting disc. Inspect the discs for chips and cracks. Grinding discs with flaws, can explode whist rotating. Replace discs when worn. Always handle both the angle grinder and individual grinding discs carefully to avoid damage.

GRINDING/CUTTING DISC ASSEMBLY:

1. Disconnect the angle grinder from the air supply.
2. To hold the spindle in place, depress the spindle lock button and rotate the spindle until the spindle lock locates and the spindle will not move.
3. Remove the outer flange nut and ensure that the inner flange is screwed-up hand-tight against the head of the angle grinder.
4. Position the flange nut depending on the thickness of the disc over the spindle and disc and hand-tighten.
5. Locate the pin wrench into the two holes on the flange nut and hand-tighten further.

DISC GUARD ADJUSTMENT:

1. Disconnect the angle grinder from the air supply.
2. Lift up the lock ring and rotate the disc guard to the desired position.
3. Let go of the lock ring and ensure it has located correctly by attempting to turn the disc guard. Never remove the disc cover completely.

MAINTENANCE

Lubricate the tool daily with a good grade of air tool oil. If no air line oiler is used, run 5ml of oil through the tool. The oil can be squirted into the tool air inlet, or into the hose at the nearest connection to the air supply, prior to operating the tool. The rust inhibitive oil is acceptable for air tools.