
RUTLAND™ SPORT

ORDER CODE
RTL-314-3020K

DIGITAL STOPWATCH

- **1/100 sec precision stopwatch with split time**
- **Calendar & time display -12/24 hour format**
- **Water resistant up to 30 metres**
- **Daily alarm**
- **Hourly chime**
- **Shock resistant**
- **LR44 1.5V Lithium button battery**

MODE SELECTION



- Press button B to switch between the stopwatch, alarm and the date/time modes.

SETTING TIME/DATE DISPLAY

- When the stopwatch is in normal time mode, press button B three times.
- Press button A to select seconds, minutes, hour, date, month or weekday.
- To change setting press button C to advance the required setting then press either button A again or button B to exit setting and return to time mode.
- To change from 12 hour mode to 24 hour mode select the time by pressing button B, (the seconds will start to flash) select the hour by pressing button A, then hold button C down continually until it changes to 24 hour mode a 'H' will appear next to the clock digits to show the mode has changed.
- To display the month, date and the weekday press button B.
- To display the time press button A until the display is showing the time (hours minutes and seconds, A/P indicates am or pm, A for morning, and P for afternoon. H stands for 24 hours mode).

ALARM DISPLAYING AND SETTING

- To display the alarm press button A.
- Press and hold down button A, press button C to sound, cancel or maintain the alarm.
- To set the alarm, press button B twice to enter setting mode.
- To change the hours and minutes press button A.
- Once set, press button B to return to the normal time mode.

STOPWATCH FUNCTION

- Press button B (mode) to select stopwatch function.
- Press button C to start the timing and C to stop timing.
- Press A to take a split time and record the time.
- Press button A again and return to accumulate time.
- Press button A to take another split time or C to stop timing.
- Press button A to clear the time and start again.

HOURLY CHIME

- For the chime to be set go to the normal mode hold down button A and press button B to display the seven day marks for the chime to be on.
- To take the chime off simply hold down button A and press button B and the seven day marks will disappear.

USER INSTRUCTIONS

CE

Please retain this information for future reference.