IND: V9_2018_AD_V2

INSTRUCTION MANUAL SIMPLIFIED OF THE STRIPPER THERMAL RS-PB150M-18 ……..version V9

The PB150M, new version with a cutting diet, has 5 buttons that you can see below with the meanings:

1-display settings

1.1 PROGRAMMING

- “M”: touch menu.

- “+”: More;

- “- “: Less;

- “V”: key validation.

- “R”: return key.

At the start of the PB you arrive on the main menu of the active program (the one that will apply to the closing of the clip, see picture above). The bar at the bottom of the main screen is a picture of the temperature of the clamp (1 bar = 10% of the set point, 2 bars = 20% of the set point...). Therefore, you will notice the presence of the following information: number of active program, its temperature (in ° C) setting and the value of tempo (in seconds, which corresponds to the maximum heating time) with 0 seconds = no tempo. From this screen you can then:

- Start the heater...
- Enter the menu of configuration via the button "M". IND: V9_2018_AD_V1 the PB150M has 3 managed menus in a circular manner through the "M" button:
- 1 press "M" takes you on the selection of the active program button menu + and - to navigate through available programs and V to validate the selection. The 'R' button to exit the Menu mode to return to the main screen.
- 1 additional support on the "M" button takes you to the menu to change the active program. To change a program must then press 'V' then choose a temperature setting via the buttons + and-, press 'V' then choose a value of tempo via the buttons + and -, press 'V' to save your changes and press again knew r 'V' to return to the main screen with the new schedule. At each step, press 'R' to go back.
- 1 additional support on the "M" button takes you to the language selection menu. Button + and - to navigate through the available languages and V to validate the selection. The 'R' button to exit the Menu mode to return to the main screen. From these commands you can so change the x programs you need (attention to the fact that change a program to him have selected beforehand) and then select as needed.

P R O G R A M M E N 1 0 - T °: 8 2 0 ° C, T E M P O: 0 6 S * P R E T *

[] NB: 860 ° C MAX. Ind TEMPERATURE

Display: V9_2018_AD_V1 to access the menu of the PB150M (hidden menu) lock (, here are the steps: 1) positioned on the main screen. (2) maintain the buttons '+' and '-' for 3 seconds; (3) release these buttons. The accessibility of the product configuration screen will appear (see below):

M E N U - A C C E S S I B I L I T E N I 1 * N I V V 2 *.

There are two possibilities:

- Level 1 = Mode operator-> modification of the programs impossible.
- Level 2 = supervisor Mode--> modification of programs possible.

You can then select the mode you want via the buttons '+' and '-' and validate your choice via the 'Validate' button. Alternatively, you can leave the menu hidden via the 'Cancel' button. IND: V9_2018_AD_V1

2-setting PLIERS TWEEZERS

2.1 setting of the trigger of the heating of ELECTRODES

In order to adjust the clamp to the different cable diameters, the latter is equipped with a height adjustment, which allows to trigger the heating of more or less tot electrodes. That is the section of the cable is important and earlier need to trigger the heating. The wheel above follows this logic. Allowing stripping of cables from AWG 30 mini section has Max AWG8 section superior cables we have developed two models of tweezers

2.1 setting the Strip length move the stop located on the top of the electrode after door face have unscrew the upper screw and adjust it has the desired length. IND: V9_2018_AD_V1

FEATURES

Power supply	230V-50Hz
Power	140W
Fuse	2A

CONTENTS

One power supply

One complete tweezer with standard electrode

One cord power supply EU TYPE

One cord power supply UK TYPE