Trapped Key Exchange – Types KE

Operating Instructions


READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING, OPERATING, OR MAINTAINING THIS EQUIPMENT.

The product is designed to be a component of a customized safety oriented control system. It is the responsibility of the user to ensure the correct overall functionality of its systems and machines. IDEM, its subsidiaries and affiliates, are not in a position to guarantee all of the characteristics of a given system or product not designed by IDEM.

INSTALLATION: Installation must only be carried out by competent personnel and in accordance with these instructions.
Always use correct size metal mounting bolts (M6). Tightening torque 2Nm.


MAINTENANCE: Every month: If the keys or housing display signs of mechanical damage then remove and replace.
IDEM will not accept responsibility for failure of the interlock functions if the installation and maintenance requirements are not implemented.
THESE INSTRUCTIONS FORM PART OF THE PRODUCT WARRANTY.






TECHNICAL SPECIFICATIONS

Body Material: Stainless steel or die cast
Operating Temperature: -25C. to +50C.
Mechanical Life (B10d) : 200,000 cycles





IDEM SAFETY SWITCHES Ltd., 2 Ormside Close, Hindley Industrial Estate, Hindley Green, Wigan, WN2 4HR UK. Tel: +44 (0)1942 257070 Fax.: +44 (0)1942 257076
IDEM (USA) 4416 Technology Drive, Fremont, CA 94538 Tel:510-445-0751 Fax:1866-431-7064 email: sales@idemsafety.com Web: www.idemsafety.com Doc.102656 Oct.17