BJ Jumper bar



Use the BJ jumper bar to connect consecutive and nonconsecutive terminal blocks with the same spacing. Two types of jumper bars are available : an assembled unit and a nonassembled unit. Both jumper bars include a metal tube which makes contact with the terminal block's internal connector bar.
To mount the BJ jumper bar accessory onto terminal blocks still having top center partitions, the user must cut out all partitions between the blocks.
When the BJ jumper bar is used with each of two series of connected blocks, the top center opening at the junction of the two series must be closed by a circuit separator or a separator end section SCM, SCF or SCD to permit different voltage potentials on each series jumper bar accessory.

BJM Assembled jumper bar

Two versions of this accessory are available.

Fractionable model, composed of captive screws on a jumper bar system. This accessory can be used for connecting consecutive blocks only.

without IP20 protection (standard)



Current capacity, Amps

BJM5	for **MA 2,5/5** blocks		
24 A	2 poles	**0176 273.01**	
24 A	3 poles	**0176 274.02**	
24 A	4 poles	**0176 275.03**	
24 A	5 poles	**0176 276.04**	
24 A	10 poles	**0176 277.05**	
BJM6	for **M 4/6** blocks		
32 A	2 poles	**0168 516.25**	
32 A	3 poles	**0168 517.26**	
32 A	4 poles	**0168 518.07**	
32 A	5 poles	**0168 519.00**	
32 A	10 poles	**0168 973.07**	
BJM8	for **M 6/8** blocks		
41 A	2 poles	**0168 520.05**	
41 A	3 poles	**0168 521.22**	
41 A	4 poles	**0168 522.23**	
41 A	5 poles	**0168 523.24**	
41 A	10 poles	**0168 974.00**	

Max. recommended torque : **0.6 Nm**

with IP20 protection (touchproof)



Current capacity, Amps

BJMI5	for **MA 2,5/5** blocks	
24 A	2 poles	**0176 278.16**
24 A	3 poles	**0176 279.17**
24 A	4 poles	**0176 280.05**
24 A	5 poles	**0176 281.22**
24 A	10 poles	**0176 282.23**
BJMI6	for **M 4/6** blocks	
32 A	2 poles	**0176 663.00**
32 A	3 poles	**0176 664.01**
32 A	4 poles	**0176 665.02**
32 A	5 poles	**0176 666.03**
32 A	10 poles	**0176 667.04**
BJMI8	for **M 6/8** blocks	
41 A	2 poles	**0176 669.16**
41 A	3 poles	**0176 670.13**
41 A	4 poles	**0176 671.00**
41 A	5 poles	**0176 672.01**
41 A	10 poles	**0176 673.02**

Max. recommended torque : **0.6 Nm**

BJD Assembled jumper bar

Only one version of this accessory is available

Simplified model, composed of a bar prepunched to the spacing of the blocks, and of captive screws and spacers. This accessory can be used for connecting blocks, which are consecutive or not : in this case remove the screw and spacer which are not required.

without IP20 protection



Current capacity, Amps

BJD6	for **D 2,5/6.D** blocks, triple deck	
24 A	2 poles	**0178 024.25**
24 A	3 poles	**0178 025.26**
24 A	4 poles	**0178 026.27**
24 A	5 poles	**0178 027.20**
24 A	10 poles	**0178 032.25**
24 A	20 poles	**0178 033.26**

Max. recommended torque : **0.6 Nm**

Simplified model, composed of a bar prepunched to the spacing of the blocks, and of captive screws and spacers. This accessory can be used for connecting blocks, which are consecutive or not : in this case remove the screw and spacer which are not required.

without IP20 protection (standard)



Current capacity, Amps

BJM5D	for **MA 2,5/5.D** blocks	
24 A	2 poles	**0176 226.22**
24 A	3 poles	**0176 227.23**
24 A	4 poles	**0176 228.04**
24 A	5 poles	**0176 229.05**
24 A	10 poles	**0176 230.02**
BJM6D	for **M 4/6.D** blocks	
32 A	2 poles	**0173 515.11**
32 A	3 poles	**0173 516.12**
32 A	4 poles	**0173 517.13**
32 A	5 poles	**0173 519.25**
32 A	10 poles	**0173 520.22**
BJM62	for **D 4/6.LNTP, DR 4/6** blocks	
32 A	2 poles	**0173 217.26**
32 A	3 poles	**0173 218.07**
32 A	4 poles	**0173 219.00**
32 A	5 poles	**0173 221.22**
32 A	6 poles	**0174 112.16**
32 A	7 poles	**0174 113.17**
32 A	8 poles	**0174 114.10**
32 A	9 poles	**0174 115.11**
32 A	10 poles	**0173 226.27**
BJM65	for **M 4/6,5.3G** blocks	
32 A	2 poles	**0174 764.03**
32 A	3 poles	**0174 765.04**
32 A	4 poles	**0174 766.05**
32 A	5 poles	**0174 767.06**
32 A	10 poles	**0174 768.17**
32 A	25 poles	**0174 769.10**
BJM10	for **M 10/10** blocks	
57 A	2 poles	**0173 611.21**
57 A	3 poles	**0173 612.22**
57 A	4 poles	**0173 613.23**
57 A	5 poles	**0173 614.24**
57 A	10 poles	**0173 615.25**
BJM12	for **M 16/12** blocks	
76 A	2 poles	**0179 618.16**
76 A	3 poles	**0179 619.17**
76 A	4 poles	**0179 620.14**
76 A	5 poles	**0179 621.01**
76 A	10 poles	**0179 622.02**
BJM16	for **M 35/16** blocks	
110 A	2 poles	**0179 613.01**
110 A	3 poles	**0179 614.02**
110 A	4 poles	**0179 615.03**
110 A	5 poles	**0179 616.04**
110 A	10 poles	**0179 617.05**
BJM4	for **DR 1,5/4** blocks	
17,5 A	2 poles	**0205 735.06**
17,5 A	3 poles	**0205 736.07**
17,5 A	5 poles	**0205 737.00**
17,5 A	10 poles	**0205 738.11**

Max. recommended torque : **0.6 Nm**
except for **BJM16 (1.2 Nm)**

with IP20 protection (touchproof)



Current capacity, Amps

BJMI5D	for **MA 2,5/5.D** blocks	
24 A	2 poles	**0176 736.21**
24 A	3 poles	**0176 737.22**
24 A	4 poles	**0176 738.03**
24 A	5 poles	**0176 739.04**
24 A	10 poles	**0176 740.11**
BJMI6D	for **M 4/6.D** blocks	
32 A	2 poles	**0179 668.20**
32 A	3 poles	**0179 669.21**
32 A	4 poles	**0179 670.26**
32 A	5 poles	**0179 671.13**
32 A	10 poles	**0179 672.14**
BJMI10	for **M 10/10** blocks	
57 A	2 poles	**0176 675.04**
57 A	3 poles	**0176 676.05**
57 A	4 poles	**0176 677.06**
57 A	5 poles	**0176 678.17**
57 A	10 poles	**0176 679.10**
BJMI12	for **M 16/12** blocks	
76 A	2 poles	**0179 626.06**
76 A	3 poles	**0179 628.10**
76 A	4 poles	**0179 629.11**
76 A	5 poles	**0179 630.16**
76 A	10 poles	**0179 631.03**

Max. recommended torque : **0.6 Nm**