

ADZC02-28/DCZC02-28/KDZC02-28



V 1.0
1/2


DCZC02-28

No	Code	Name of Spare Parts	Remark
1	30010000512	Chuck Cover	
1	30010000597	Chuck Cover (SDS)	
2	30029902315	Retainer Ring For Shaft 20.7 (New)	
3	30029902273	Support Ring	
3	30029902702	Support Ring (SDS)	
4	30019901681	Chuck Sleeve	
4	30019901938	Chuck Sleeve (SDS)	
5	30024500381	Spring	
6	30029902257	Spring Stop	
7	30021600006	Circlip For Hole 47	
10	30029902522	Flat Washer	
12	30010300111	O Ring For Chuck Body	
13	30021000003	Steel Ball 9/32’ (7.14)	
14	30029902259	Chuck Body	
14	30029902701	Chuck Body (SDS)	
15	30021000005	Steel Ball 5/16’ (7.94)	
16	30010000510	Sealing Ring 2	
17	30029902256	Striker Pin	
18	30029902258	Striker	
19	30010000558	O Ring For Striker	
20	30021600016	Circlip For Shaft 30	
21	30021400126	Ball Bearing 6906ZZ	
22	30029902261	Adapter Sleeve	
23	30029902525	Cylinder	
24	30029902314	Clutch Washer	
25	30024500380	Clutch Spring	
26	30029902264	Push Plate	
27	30021000011	Steel Ball 6.5	
28	30029902524	Clutch Sleeve (Long)	
29	30029902523	Flat Washer 4	
30	30029902271	Cylinder Sleeve	
31	30029902521	Lockwasher	
32	30029902520	Flat Washer 1	
33	30029902265	Special Retainer Ring 30	
34	30029902519	Spline Housing	
35	30029902518	Ring For Gear Shift	
37	30021500203	Piston Pin	
38	30019901825	Piston	
39	30010000511	O Ring	
40	30019901826	Connecting Rod	
41	30021200048	Pan Head Tapping Screw ST4.2×17	
42	30115410139	Motor Housing Assembly (Blue)	
43	30010000513	Frame Oil Seal 14.3×22.5×6	
44	30021400452	Front Bearing Of Motor	
45	30023700106	Bearing Retainer	
46	30021100010	Cross Recessed Pan Head Screw M5×10 (With Spring And Flat Washers)	
47	30016000139	Air-Deflector Ring	
48	30400200050	Armature DongCheng	
49	30021400245	Ball Bearing 607-2RS	
50	30400300041	Stator DongCheng	
51	30415400274	Motor Housing (DongCheng)	
52	30019902057	Cover_LED	



DCZC02-28

No	Code	Name of Spare Parts	Remark
53	30021100011	Cross Recessed Pan Head Screw M5×30 (With Spring And Flat Washers)	
54	30030200369	Controller	
55	30030100433	Signal Switch (Red)	
56	30019901498	Terminal Socket	
57	30021200122	Pan Head Tapping Screw ST3.5×16	
58	30015500051	Rear Cover Of Motor Housing	
59	30019901821	Function Switch (Black)	
60	30024500418	Guide Spring	
61	30019901822	Lock Button (Red)	
66	30021100089	Cross Recessed Small Pan Head Screw With Spring Washer M5×16	
68	30010000516	Sealing Ring 4	
74	30029902269	Flat Washer 3	
75	30021400417	Deep Groove Ball Bearing 6900-2RS	
76	30029902266	Gear Bush	
77	30021600696	Split Washer 6	
81	30029902270	Flat Washer 2	
82	30020700145	Gearbox Shaft	
83	30023300168	Gearbox	
84	30009800939	Damping Spring Assembly	
85	30010000635	Damping Rubber A	
86	30115600088	Handle Assembly	
87	30010000636	Damping Rubber B	
88	30021200043	Pan Head Tapping Screw ST4×37	
89	30010200013	Rubber Pin	
90		Battery Pack	
91		Battery Charger	
861	30029902268	Clamping Band	
862	30021100175	Trapezoid Square-Neck Bolt M8×40	
863	30019901682	Auxiliary Handle Support	
864	30019901828	Push Button_Red	
865	30024500379	Compression Spring	
866	30015800027	Auxiliary Handle	
867	30029902267	Depth Gauge	
T1	30009800940	Oil Seal Bracket Assembly	Including：8, 9, 11
T2	30009801082	Gear Assembly	Including：36, 72, 73
T3	30009801083	Gearbox Assembly	Including：30, 76, 82, 83
T4	30009801084	Gearbox Cover Assembly	Including：59-65, 67, 69-71
T5	30009800944	Hammer Gear Assembly	Including：78, 79, 80
T6	30019902058	Auxiliary Handle Assembly	Including：861-866
T7	30009801172	Function Switch Assembly	Including：59-61



V 1.0
2/2