




PBL5201

ITEM :	SPARE PART ENG. NAME :	QTY :
1	Round mouth pipe	1
2	Extension Blower Pipe	2
3	Switch	1
4	Hex Screw M6*45	1
5	Switch Seat	1
6	Butter Nut	1
7	Main Blower Pipe	1
8	Clamp Small	1
9	Bellows	1
10	Clamp Big	1
11	Corner Joint	1
12	Hex Screw Combined	7
13	Starter	1
14	Aluminum gasket	1
15	Cross Screw	13
16	Housing	1
17	Flage Nut	1
18	Aluminum Plate	1
19	Flat washer	1
20	Oil Seal	1
21	Right Case	1
22	Case Gasket	1
23	Bearing	2
24	Cross Screw	3
25	Ignition Cover	1
26	Hex Combined Screw	2
27	Ignition Coil	1
28	Flameout Line	1
29	Round Pin	2
30	Crankshaft	1
31	Hex Combined Screw	6
32	Left Case	1
33	Oil Seal	1
34	Needle	1



ITEM :	SPARE PART ENG. NAME :	QTY :
35	Piston Pin Circlip	2
36	Piston Pin	1
37	Piston	1
38	Piston Ring	2
39	Cylinder Gasket	1
40	Cylinder	1
41	Muffler Gasket Small	1
42	Muffler Gasket Big	1
43	Muffle	1
44	Hex Combined Screw	1
45	Muffler Cover	1
46	Hex Combined Screw	2
47	Hex Combined Screw	4
48	Spark Plug	1
49	Intake Tube Gasket	2
50	Air Deflector	1
51	Intake Tube	1
52	Hex Combined Screw	8
53	Hex Combined Screw	4
54	Woodruff Key	1
55	Flywheel	1
56	Hex Flange Nut	1
57	Carburetor Gasket	1
58	Carburetor	1
59	Cross Screw	2
60	Ventilation Switch	1
61	Air Filter Support	1
62	Hex Combined Screw	2
63	Ventilation Cover	1
64	Anti-Ventilation	1
65	Air Filter	1
66	Air Filter Cover	1
67	Spring Anti-Vibration 2	2
68	Anti-Vibration Spring	2



ITEM :	SPARE PART ENG. NAME :	QTY :
69	Hex Combined Screw	2
70	Spring Anti-Vibration 1	2
71	Cross Screw	9
72	Tension Disc	2
73	Ventilation cover of back wind cover	1
74	Hex Nut	2
75	Back Wind Cover	1
76	Wind Fly	1
77	Front Wind Cover	1
78	Cros Screw	2
79	Hex Combined Screw	1
80	Shoulder Brace Spring Anti-Vibration	1
81	Hex Nut	2
82	Shoulder Belt	1
83	Buckle	7
84	Cushion	1
85	Aluminum Gasket 5	3
86	Shoulder Brace	1
87	Flat washer	2
88	Hex Combined Screw	2
89	Left Protection Net	1
90	Shoulder Belt Buckle	2
91	Fuel Tank	1
92	Blancer	1

