REX

รายการอะไหล่ REX N80A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
N80A	1. BASE	3		W082	HEX SOCKET HEAD CAP SCREW
N80A	1. BASE	4		F003	REAR COVER
N80A	1. BASE	5		W06A	HEX SOCKET HEAD CAP SCREW
N80A	1. BASE	7		W251	ROUND HEAD MACHINE SCREW
N80A	1. BASE	8		4905	MAIN SHAFT BEARING
N80A	1. BASE	9		WL41	ROLL PIN
N80A	1. BASE	10		F009	THRUST RING
N80A	1. BASE	11		F022	OIL TUBE COVER
N80A	1. BASE	12		WW16	SNAP RING
N80A	1. BASE	13		WX16	RETAING RING
N80A	1. BASE	14		N039	OIL CAP
N80A	1. BASE	15		W684	HEX SOCKET SET SCREW
N80A	1. BASE	16		WA42	DRAIN PLUG
N80A	1. BASE	17	R022-3090	4047	STRAINER
N80A	1. BASE	18		0410-100	OIL LINE TUBE RED (INTAKE)
N80A	1. BASE	19			ROUND HEAD TAPPING SCREW
N80A	1. BASE	20		T056	NIPPLE
N80A	1. BASE	21		ZJ50	PIPE BAND S
N80A	1. BASE	22	R022-2550	F018	TANK UPPER COVER
N80A	1. BASE	23		N029	OIL FILTER
N80A	1. BASE	24		F016	SCRAP RECEIVER
N80A	1. BASE	26		7098	BINDER C-15
N80A	1. BASE	27		W242	ROUND HEAD MACHINE SCREW
N80A	1. BASE	28		F015	SIDE COVER
N80A	1. BASE	29		F027	CAP
N80A	1. BASE	30		F132	WARNING PLATE (DISCONTINUED)
N80A	1. BASE	31		L002	NAME PLATE (DISCONTINUED)
N80A	1. BASE	32		W241	ROUND HEAD TAPPING SCREW
N80A	1. BASE	34		W4A4	OVAL HEAD MACHINE SCREW
N80A	1. BASE	37		WN34	RIVET
N80A	1. BASE	38		F085	BOTTOM COVER SPONGE
N80A	1. BASE	41		W085	HEX SOCKET HEAD CAP SCREW
N80A	1. BASE	42		W082	HEX SOCKET HEAD CAP SCREW
N80A	1. BASE	43		N121	PIPE STAND WITH N125 LEG CAP
N80A	1. BASE	44		N125	LEG CAP
N80A	1. BASE	45		02FY	PIPE STAND COMPLETE SEST (#39-44)
N80A	1. BASE	46		W4A6	OVAL HEAD MACHINE SCREW
N80A	1. BASE	47		7552	MACHINE COVER
N80A	1. BASE	1-A		F001	BASE CASTING ASSEMBLY

REX

รายการอะไหล่ REX N80A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
N80A	1. BASE	25-A		7021	CORD BUSH
N80A	1. BASE	2-A		FM26	GEAR COVER
N80A	1. BASE	33-C		FSW1	FOOT SWITCH
N80A	1. BASE	33-C		N122	CABTYRE CORD EX
N80A	1. BASE	35-A	R022-3120	N008	SWITCH
N80A	1. BASE	35-B		F065	CAM SWITCH R/L
N80A	1. BASE	36-A		N041	SWITCH FIXED PLATE
N80A	1. BASE	36-B		F066	CAM SWITCH FIXED PLATE R/L
N80A	1. BASE	39-A		WA61	WING SCREW
N80A	1. BASE	40-B		F060	STAND BASE
N80A	1. BASE	6-A		F017	BOTTOM COVER
N80A	2. MOTOR, PUMP	1		FM25	HOUSING
N80A	2. MOTOR, PUMP	2	R022-2040	FM16	CARBON BRUSH HOLDER (DISCONTINUED)
N80A	2. MOTOR, PUMP	3	R022-2010	FM10	CARBON BRUSH
N80A	2. MOTOR, PUMP	4	R022-2060	FM17	CARBON BRUSH CAP
N80A	2. MOTOR, PUMP	6		FM15	STOP PLATE (DISCONTINUED)
N80A	2. MOTOR, PUMP	7			ROUND HEAD MACHINE SCREW WITH SPRING WASH
N80A	2. MOTOR, PUMP	8		FM27	FAN GUIDE (DISCONTINUED)
N80A	2. MOTOR, PUMP	10		S701	BEARING
N80A	2. MOTOR, PUMP	11		NM43	DISTANCE PIECE
N80A	2. MOTOR, PUMP	12		I202	BEARING
N80A	2. MOTOR, PUMP	13		FM28	INNER COVER (DISCONTINUED)
N80A	2. MOTOR, PUMP	14		FM26	GEAR COVER
N80A	2. MOTOR, PUMP	15		FM24	SPINDLE
N80A	2. MOTOR, PUMP	16		NM23	FINAL GEAR
N80A	2. MOTOR, PUMP	17		FM46	WOODRUFF KEY
N80A	2. MOTOR, PUMP	18		7M30	BEARING
N80A	2. MOTOR, PUMP	19	R022-2062	FM22	THIRD PINYON GEAR
N80A	2. MOTOR, PUMP	20	R022-2063	FM20	SECOND PINyON GEAR
N80A	2. MOTOR, PUMP	21		WG06	SPRING WASHER
N80A	2. MOTOR, PUMP	22			ROUND HEAD MACHINE SCREW WITH SPRING WASH
N80A	2. MOTOR, PUMP	23		WI09	WASHER B
N80A	2. MOTOR, PUMP	24		FM47	BEARING LOCK (DISCONTINUED)
N80A	2. MOTOR, PUMP	25		FM14	INTERNAL WIRE ASSEMBLY (BLUE) (WITH #26)
N80A	2. MOTOR, PUMP	26		FM14	INTERNAL WIRE ASSEMBLY (RED)
N80A	2. MOTOR, PUMP	27			INSALATION CAP
N80A	2. MOTOR, PUMP	28	R022-2530	F80P	GEAR PUMP SET WITH JOINT
N80A	2. MOTOR, PUMP	29		W042	HEX SOCKET HEAD CAP SCREW
N80A	2. MOTOR, PUMP	30		1035	JOINT

REX

รายการอะไหล่ REX N80A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
N80A	2. MOTOR, PUMP	31		ZJ50	PIPE BAND
N80A	2. MOTOR, PUMP	32		0410-550	OIL LINE TUBE RED (INTAKE)
N80A	2. MOTOR, PUMP	33	R022-3130	0410-700	OIL LINE TUBE RED (FEED)
N80A	2. MOTOR, PUMP	5-A	R022-2020	FM08	STATOR ASSEMBLY
N80A	2. MOTOR, PUMP	9-A	R022-2050	FM04	ARMATURE ASSEMBLY
N80A	3. MAIN SHAFT	2	R022-3150	F080	HAND WHEEL
N80A	3. MAIN SHAFT	8	R022-2656	W07A	HEX SOCKET HEAD CAP SCREW
N80A	3. MAIN SHAFT	10	R022-2547	F0S3	REAR SCROLL
N80A	3. MAIN SHAFT	13	R022-3210	F0SS	REAR CHUCK JAW
N80A	3. MAIN SHAFT	14			REAMER SCREW
N80A	3. MAIN SHAFT	15			ROUND HEAD MACHINE SCREW
N80A	3. MAIN SHAFT	16		WG05	SPRING WASHER
N80A	3. MAIN SHAFT	17		WC05	NUT
N80A	3. MAIN SHAFT	18		WM64	ROLL PIN
N80A	3. MAIN SHAFT	19		F008	SELF-ADJUSTING THRUST RING
N80A	3. MAIN SHAFT	20		WC06	U-NUT
N80A	3. MAIN SHAFT	21		F030	SPRING
N80A	3. MAIN SHAFT	22		W069	HEX SOCKET HEAD CAP SCREW
N80A	3. MAIN SHAFT	11-A	R022-2540	F0S1	REAR CHUCK RECEPTACLE
N80A	3. MAIN SHAFT	12-A	R022-2545	F0S2	REAR CHUCK COVER
N80A	3. MAIN SHAFT	1-A	R022-2635	02F1	MAIN SHAFT COMPLETE SET
N80A	3. MAIN SHAFT	3-A	R022-3220	4980	CHUCK COMPLETE SET (#4-7)
N80A	3. MAIN SHAFT	4-A	R022-3170	FS00	CHUCK SCROLL
N80A	3. MAIN SHAFT	5-A	R022-3160	FH01	CHUCK BODY
N80A	3. MAIN SHAFT	6-A	R022-2510	4FCJS	CHUCK JAW SET (#6-7)
N80A	3. MAIN SHAFT	7-A	R022-3240	70RT	CHUCK JAW INSERT SET
N80A	3. MAIN SHAFT	9-A		F020	REAR CHUCK COMPLETE SET (#10-17)
N80A	4. CARRIAGE, MOTOR	1		F004	CARRIAGE
N80A	4. CARRIAGE, MOTOR	2		F010	CARRIAGE SUPPORT BAR A
N80A	4. CARRIAGE, MOTOR	3		F011	CARRIAGE SUPPORT BAR B
N80A	4. CARRIAGE, MOTOR	4		F081	CARRIAGE SUPPORT COLLAR (DISCONTINUED)
N80A	4. CARRIAGE, MOTOR	5	R022-2520	F013	CARRIAGE HANDLE
N80A	4. CARRIAGE, MOTOR	6		WM53	GROOVED PIN
N80A	4. CARRIAGE, MOTOR	7	R022-2555	G044	OIL TUBE CONNECTOR
N80A	4. CARRIAGE, MOTOR	8		W665	HEX SOCKET SET SCREW
N80A	4. CARRIAGE, MOTOR	9		F032	NIPPLE
N80A	4. CARRIAGE, MOTOR	10		0410-120	TUBE
N80A	4. CARRIAGE, MOTOR	11		FM43	DISTANCE PIECE
N80A	4. CARRIAGE, MOTOR	12		ZJ50	PIPE BAND S

KTW KRIENG THAI WATANA GROUP

23 มิถุนายน 2563

PRICE LIST

REX

รายการอะไหล่ REX N80A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
N80A	4. CARRIAGE, MOTOR	13		G861	OIL NOTCH
N80A	4. CARRIAGE, MOTOR	14	R022-2030	F062T	MOTOR R (DISCONTINUED)
N80A	4. CARRIAGE, MOTOR	15	R022-2040	FM16	CARBON BRUSH HOLDER (DISCONTINUED)
N80A	4. CARRIAGE, MOTOR	16	R022-2010	FM10	CARBON BRUSH
N80A	4. CARRIAGE, MOTOR	17	R022-2060	FM17	CARBON BRUSH CAP
N80A	4. CARRIAGE, MOTOR	18	R022-2530	F80P	GEAR PUMP COMPLETE SET (#24-37)
N80A	4. CARRIAGE, MOTOR	19	R022-2655	1035	JOINT
N80A	4. CARRIAGE, MOTOR	20		0410-550	OIL LINE TUBE RED (INTAKE)
N80A	4. CARRIAGE, MOTOR	21	R022-3130	0410-700	OIL LINE TUBE RED (FEED)
N80A	4. CARRIAGE, MOTOR	22		W68A	HEX SOCKET SET SCREW
N80A	4. CARRIAGE, MOTOR	23		W051	HEX SOCKET HEAD CAP SCREW
N80A	4. CARRIAGE, MOTOR	24		Z5S6	O-RING
N80A	4. CARRIAGE, MOTOR	25		WG08	SPRING WASHER
N80A	4. CARRIAGE, MOTOR	26		W083	HEX SOCKET HEAD CAP SCREW
N80A	4. CARRIAGE, MOTOR	27		1013	MOTOR FIXED PIN
N80A	4. CARRIAGE, MOTOR	28		W686	HEX SOCKET HEAD SCREW
N80A	4. CARRIAGE, MOTOR	29		WC08	JAM NUT
N80A	4. CARRIAGE, MOTOR	30		1076	CUTTER ARM STOP PIN
N80A	4. CARRIAGE, MOTOR	31		1096	REAMER ARM STOP PIN
N80A	5. CUTTER	2	R022-3250	8071	CUTTER FRAME
N80A	5. CUTTER	3	R022-2630	F012	CUTTER HANDLE
N80A	5. CUTTER	4	R022-2560	F024	CUTTER GUIDE
N80A	5. CUTTER	5		135076	CUTTER WHEEL
N80A	5. CUTTER	6	R022-3320	2471	CUTTER PIN S
N80A	5. CUTTER	7		WN16	SPRING COTTER
N80A	5. CUTTER	8	R022-2590	3463	CUTTER BUSH
N80A	5. CUTTER	9	R022-2580	1302	THRUST BEARING ASSEMBLY
N80A	5. CUTTER	10	R022-2570	F025	FEED SCREW
N80A	5. CUTTER	11		WL65	ROLL PIN
N80A	5. CUTTER	12	R022-3330	5079	CUTTER PIN L
N80A	5. CUTTER	13	R022-3290	5074	CUTTER ROLLER
N80A	5. CUTTER	14	R022-2600	8074	CUTTER ARM (#14-16)
N80A	5. CUTTER	15			KEY (WR04)
N80A	5. CUTTER	16			ROLL PIN
N80A	5. CUTTER	17	R022-3292	8075	STOP RING
N80A	5. CUTTER	18	R022-3293	WL37	ROLL PIN
N80A	5. CUTTER	19			CUTTER ARM SET (#14-18)
N80A	5. CUTTER	1-A	R022-3310	0FCU1S	CUTTER COMPLETE SET
N80A	6. REAMER	1		0FRM1S	COMPLETE REAMER ASSEMBLY

REX

รายการอะไหล่ REX N80A

รุ่น	PART LOCATION	PART NO.	KT-CODE	REX CODE	DESCRIPTION
N80A	6. REAMER	2		F119	REAMER ARM
N80A	6. REAMER	3		1092	REAMER SHAFT
N80A	6. REAMER	4		1094	REAMER KNOB
N80A	6. REAMER	5		WL41	ROLL PIN
N80A	6. REAMER	6	R022-3340	8093	REAMER CONE
N80A	6. REAMER	7		WL86	ROLL PIN
N80A	6. REAMER	8		WLA1	ROLL PIN
N80A	6. REAMER	9		5096	SPRING
N80A	6. REAMER	10		WQ08	STEEL BALL