
Exploded view BG5



PART LIST BG5

Explosion No.	Description	Quantity
1	Grinder Wheel	1
2	Cross bolt three combination	2
3	Screw	2
4	Eyeshield Bracket	2
5	Washer	8
6	Spring washer	8
7	Nut	10
8	Eyeshield	2
9	Bearing	2
10	base	1
11	Rotor	1
12	Stator	1
13	Nameplate	1
14	Middle ring	1
15	Cover	2
16	Right Inner guard	1
17	A fixed pressing plate	1
18	Wheel flange	4
19	Nameplate of wheel	4
20	Grinder Wheel	1
21	Nut	1
22	Right outer guard	1
23	Screw	6
24	Square Neck Screw	2
25	Right tool rest	1
26	Tooth washer	2
27	Washer	2
28	Knob nut	2
29	Spring washer	2
30	Cross bolt three combination	4
31	Switch	1
32	Tooth washer	1
33	Ground terminal	1
34	Screw	1
35	Rubber Feet	4
36	Base plate	1
37	Screw	2
38	Spring washer	1
39	Capacitor	1
40	Screw	1
41	Plug & Cable	1
42	Left Inner guard	1
43	Nut	1
44	Left Outer guard	1
45	Left tool rest	1
46	Screw	2
47	Cable adaptor	1
48	Screw	2
49	Cable clip	1