

MB-13A exploded view



MB-13A exploded view



Part No.	Description	Part No.	Description
1	Side plate	70	Bearing 696_2Z
2	Top cover hand protection rubber sleeve	71	Middle gear shaft
3	Cover	72	Middle gear
4	Hexagon socket head cap screw M8x10	73	Needle roller bearing HK0810
5	Counter nutM14X1.5	74	Gear box cover steel sleeve
6	Self tapping screwA-ST4.2X10	75	Semicircular key
7	Chip cover handle	76	Output shaft
8	Chip discharge cover	77	Big gear wheel
9	Timing nutM14X1.5	78	Gear box steel sleeve
10	Fixing screw of chip discharge cover	79	Gear box
11	Circlip 7 for shaft	80	Wind shield
12	Hand wheel	81	Bearing6200_2RZ
13	Hand wheel connecting pin	82	Rotor
14	Indicator	83	Flat washer class C M10
15	Rocking handle	84	Stator
16	Pan head screwM5X20	85	Casing
17	Elastic cylindrical pin 4x30	86	Small pulley
18	Flat washer M5	87	Belt
19	Connecting button	88	Belt cover
20	Main frame	89	Tension spring
21	Outer hexagon nut	90	Carbon brush
22	Filament rod (orthodontic)	91	Brush holder cover
23	Three combination machine screw M4x8	92	Self locking
24	Elastic cylindrical pin 6x26	93	Small spring (hook spring)
25	With fish head	94	Countersunk screw M4X10
26	Outer hexagon screw M6X20	95	Large washer M6
27	Outer hexagon nut M6	96	Step screw M5X16 head Φ eleven
28	Workbench	97	Indicator block
29	Front and rear plates	98	Self tapping screw A-ST4_2X25
30	Polished rod	99	Pan head screw M4X14
31	Three combination machine screw M4X28	100	Three combination machine screw M4X25
32	Bevel gear cover	101	Three combination machine screw M5X30
33	Thick umbrella tooth	102	Bearing 696ZZ
34	Jam nut M10	103	Bearing 6203_2RS
35	Flat umbrella tooth	104	Cutter shaft iron core short
36	Socket head cap screw M8X16	105	Blade
37	Steel sleeve 16X10.1X8.2H	106	Knife pressing strip
38	Bearing 6000	107	Square nut M6X5
39	Screw rod bearing gland	108	Outer hexagon screw M6X12
40	Pan head screw M4X10	109	Blade support spring
41	Floor	110	Cutter shaft body
42	Wave bar	111	Cutter shaft core length
43	Three combination machine screw M4X10	112	Flat key 4x4x18
44	Short screw rod (reverse tooth)	113	Cutter shaft bearing cover
45	Guide post	114	Countersunk screw M5X12
46	Switch	115	Large pulley
47	Pan head tapping screw ST2.9X9.5	116	Sprocket gasket
48	Switch cover	117	Spring washer 6
49	Switch trigger	118	Outer hexagon screw M6X16
50	Indicator light	119	Three combination machine screw M5X12
51	Capacitance	120	Rubber stick pressing cover
52	Switch connecting wire	121	Rubber stick square steel sleeve
53	Wiring block	122	Rear rubber stick spring (large)
54	Switch seat	123	Front rubber stick spring (small)
55	Countersunk head tapping screw ST2.9X13	124	Glue stick

Part No.	Description	Part No.	Description
56	Junction box cover	125	Sprocket
57	Junction box	126	Long chain
58	Three combination machine screw M4X12	127	Steel sleeve 18X12X15H
59	Self tapping screw A-ST4.2X19	128	Steel sleeve 18X12X18H
60	Crimping plate	129	Short chain
61	Sheath	130	Jam nut M8
62	Cable plug	131	Tool holder
63	Cylindrical pin	132	Cross screwdriver
64	Pan head tapping screw ST4.8X75	133	Packing carbon brush
65	Pan head tapping screw ST4.8X80	134	Open end wrench
66	Gearbox cover	135	Inner hexagon spanner
67	Copper sleeve	136	Tool kit
68	Pinion shaft	137	Dust cover
69	Pinion		