
Exploded view Model: WBS8



Part No.	Description	Part No.	Description
1	Parallel Rip Fence Assemble	44	Cross Recessed Pan Head Screw
2	Compound Nut	45	Door Upper
3	Working Table	46	Circlip For Shaft
4	Suctoin Connector	47	Upper Wheel
5	Table Insert	48	Cup Head Square Neck Bolt
6	Cup Head Square Neck Bolt	49	Brush
7	Indicator	50	Spacer Bushing
8	Guide piece	51	Switch
9	Cup head square neck bolt	52	Cross Recessed Countersunk Head Screw
10	Table trunnion lower	53	Switch Plate
11	Washer	54	Bearing Bolt Upper
12	Table trunnion upper	55	Circlip For Shaft
13	Locking Pin	56	Bearing Bolt Support Upper
14	Thrust Bearing Shaft	57	Hex. Flanged Nut
15	Housing Upper Guide	58	Blade Tensioner
16	Hex. Socket Set Screw	59	Guide Plate Assemble
17	Upper Pilot Pin	60	Pin Guide
18	Bearing	61	Guide Piece
19	Hex. Socket Set Screw	62	Hex. Bolt
20	Hex. Socket Set Screw	63	Hex. Flanged Nut
21	Cross Recessed Pan Head Tapping Screw	64	Cup Head Square Neck Bolt
22	Seat Upper Guide	65	Lower Blade Guard
23	Guide Lever	66	Hex. Locking Nut
24	Cup Head Square Neck Bolt	67	Hex. Bolt
25	Shaft	68	Motor
26	Cover Board	71	Locking Knob
27	Slide Board	72	Power Cord And Plug
28	Lower Pilot Pin	73	Setting Knob
29	Housing Lower Guide	74	Spring
30	Rack	75	Dishing Cover
31	Hex. Bolt	76	Setting Knob
32	Spring Washer	77	Setting Knob
33	Band Saw Tyre	78	Hex. Bolt
34	Lower Wheel	79	Wing Knob
35	Saw Blade	80	Butterfly Spring
36	Hexagon socket cap head screw	81	Shaft
37	Washer	82	Thread Bolt
38	Door locker	83	Lamella Plug
39	Door Lower	84	Frame
40	Serrated lock washer	85	Nut
41	Fan cover	86	Spacer bush
42	Hexagon socket cap head screw	87	Hx. Hd. Lock nut
43	Washer	88	Angle Gauge Components