THE ENVIRONMENT

Always dispose of unwanted tools, accessories and packaging materials in an environmentally friendly manner.

In observance of the European Directive on Waste Electrical and Electronic Equipment (WEEE) and its implementation in accordance with national law, electrical goods that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility.

Do not dispose of electrical goods with domestic waste materials as inappropriate disposal may cause potential hazards to the environment and human health.

For further information, please contact your local authority or the retailer from whom you purchased the product.

This product does not contain any restricted substances in concentrations and applications which are banned by the European RoHS2 Directive.

DECLARATION OF CONFORMITY

We hereby certify that the OSAKI ENG003 ELECTRIC ENGRAVER KIT

(ORDER CODE: OSA-279-9810K)

complies with all the relevant provisions of the

Machinery Directive 2006/42/EC

Standards Applied: EN 60745-1:2009+A11:2010

EMC Electromagnetic Compatibility Directive 2014/30/EU

Standards Applied: EN 55014-1:2006/+A1:2009/+A2:2011, EN 55014-2:2015, EN 61000-3-2:2014, EN 61000-3-3:2013

RoHS2 Restriction of Hazardous Substances Directive 2011/65/EU

Standards Applied: EN 50581-1:2012

Signed:

Date: 24th January 2021

Name: Toni Johonson

Position: Compliance Director

Official Agent

KENNEDY TOOLS

Cromwell Group (Holdings) Limited.
65 Chartwell Drive, Wigston, Leicestershire,
England, LE18 2FS

Contact Us: contactus@cromwell.co.uk

Country of Origin : China

CE UKCA

QUALITY GUARANTEE & WARRANTY

OSAKI POWER TOOLS carry a one year manufacturer's warranty.

OSAKI POWER TOOLS are designed & produced to the highest standards & specifications.

OSAKI POWER TOOLS are fully guaranteed against faulty materials & workmanship.

Should they be found to be defective, they will either be repaired or replaced free of charge (fair wear and tear and/or misuse excepted). This does not affect your legal rights.
Please retain supplier invoice as proof of purchase.

OSAKI POWER TOOLS are designed for DIY and hobby use only.
They are not covered by an industrial warranty. Industrial use will invalidate this guarantee.

Specifications may change without prior notice. E&EO

Cromwell Group (Holdings) Limited.
65 Chartwell Drive, Wigston, Leicestershire, England, LE18 2FS
© The Kennedy Group Ltd. 12/21

OSAKI POWER TOOLS

ELECTRIC ENGRAVER KIT

ENG003

ORDER CODE
OSA-279-9810K



- 5-Position adjustable engraving depth
- 6000rpm
- Soft grip
- Positive on/off
- 1.8m Cable
- Includes 2 tips and template for letters and numbers

CE UKCA

WARNING: THE SAFETY INFORMATION GIVEN INSIDE MUST BE READ AND UNDERSTOOD BY ANY PERSON USING, INSTALLING, REPAIRING OR MAINTAINING THIS PRODUCT.

OPERATOR'S MANUAL

Please retain this information for future reference.

SAFETY INSTRUCTIONS

Osaki Power Tools are committed to the Production of Quality Power Tools that are designed for high performance and long service life. If safety and maintenance procedures are observed they will last for many years.

"Man, Earth and the Universe are forces that create an immovable centre of balance . . . OSAKI POWER TOOLS the balance of power"

GENERAL SAFETY

- Always keep your work area clean and tidy and ensure it is always well lit. Cluttered dark areas may cause accidents.
- Always use the power tool and accessories in accordance with these instructions and in the manner the tool is intended.
- Always stay alert to ensure your personal safety at all times and do not use the engraver when tired or under the influence of medication, alcohol or drugs.
- Always plug the engraver into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances. Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded.
- Always keep children away from work area.
- Always ensure the engraver is OFF before plugging in to the mains in order to avoid any accidents
- Always ensure the mains power supply corresponds to the power rating on the data label on the machine.
- Always disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools.
- Always wear eye protection.
- Never operate tools in the presence of flammable liquids, gases or dust; power tools create sparks that could potentially ignite dust or fumes.
- Never allow inexperienced people to use the engraver without supervision.
- Never expose the engraver to rain or wet conditions.
- Never carry the engraver by the cable and do not use the tool at all if the cable is damaged.
- Never use the engraver with a blunt tip: cutting tools with sharp cutting edges are easier to control.


SPECIFICATIONS

Model Number	ENG003
Order Code	OSA-279-9810K
Nominal Voltage	230v~50 Hz
RPM	6000
Vibration Level	1.76m/s2
Sound Power Level	65dBA
Sound pressure Level	76dBA
Power Cord Length	1.8m
Net Weight engraver	375g


OPERATING INSTRUCTIONS

To ensure the best possible use of the Osaki Engraver tool please follow these simple operating instructions.

1. Before you start using the engraver you must firstly install the engraver tip. To do this you must unscrew the grub screw which is located in the engraver point holder. Place the engraver tip inside the tip holder and firmly tighten the grub screw (see Fig. 1). It is important to ensure that the tip is held firmly in place by the grub screw. In order to replace a worn out tip the same procedure should be followed. Replacement engraver tips are available from your local supplier; please quote order code OSA-280-3100A (pack of 5 tips).


Fig. 1

2. This engraver is powered by an AC motor, therefore you will need to ensure that the current you are using is the same as shown on the label of the engraver unit. To use the engraver, turn it "ON" by moving the on/off switch located at the end of the engraver housing (see Fig. 2). Then hold the engraver at a slight angle (as if holding a pencil) and ensure your arm is comfortable by resting it on a table. It is recommended that you start by familiarising yourself with the tool by experimenting on a few bits of scrap material and when you are ready to start work select the setting to produce an engraving mark to meet your requirements. Use a light touch to guide the tip and for maximum results work slower than you would normally write.


Fig. 2

CAUTION: NEVER USE THE ENGRAVER WITH A BROKEN TIP.

3. To control the stroke length and depth of engraving use the adjustment dial on the side of the engraver housing (see Fig. 3), please note this dial cannot be used as an OFF switch. The lowest setting is pointing to number one and the highest is number five.




Fig. 3

4. The engraver tip is carbide steel and under most conditions it will perform very satisfactorily on hard materials such as glass, ceramics and steel. Do not engrave electronic media such as DVDs, CDs etc. Engraving on these materials will damage the media.