CROMWELL®
PACKAGING INFORMATION LEGEND

ARTWORKER & DATE: DAVID (08/2016)
PRODUCT TITLE: EC2 ELECTRONIC TALLY COUNTER UP ONLY
OUR ORDER CODE(S): OXD-314-5820K
ARTWORK TYPE: INSTRUCTION SHEET
PRINT SIZE: 60mm x 115mm
PRINT POSITION: SEE IMAGE BELOW
PRINT COLOUR(S): 1 - BLACK

COLOUR SWATCHES:

BLACK

CUTTER (DO NOT PRINT)

OXFORD PRECISION

OXD-314-5820K

ELECTRONIC TALLY COUNTER (up only)

OPERATING INSTRUCTIONS

- **To switch on** - Press on/off/reset button. The unit will display '0'
- **To count** - Press the count button, it will beep on each count
- **To switch beep off or on at any time** - Hold the count button down for 3 seconds
- **To reset tally** - Press on/off/reset button for 3 seconds
- **To switch the tally off** - Press the on/off/reset button for 3 seconds when the counter display is at '0'

BATTERY INFORMATION
Battery type: AG10 1.5V Button cell.
Observe polarity (+/-) during replacement.
Do not over tighten screws.

SAFETY
Retain this information for future reference.
This product contains glass and may cause injury if broken.
This is not a toy hence is not suitable for children under 3 years of age.

DECLARATION OF CONFORMITY

We hereby certify that EC2 ELECTRONIC TALLY COUNTER UP ONLY (ORDER CODE: OXD-314-5820K) complies with all the relevant provisions of the Restriction of the use of certain hazardous substances (RoHS2) 2011/65/EU
Standards Applied: EN 50581-1:2012

Signed: Date: 1st August 2016
Name: Keith Read
Position: HSQE Team.

Leicester, England, LE18 2FS