

คู่มือการใช้งาน เครื่องฟอกอากาศอัจฉริยะ **xiaomi 4** .1

Xiaomi Smart Air Purifier 4 User Manual .10



คำเตือน


- เมื่อสายไฟเกิดความเสียหาย จะต้องเปลี่ยนสายไฟใหม่ที่เป็นของแท้ ซึ่งซื้อจากผู้ผลิต หรือ ฝายบริการหลังการขายทันที
- เด็กอายุตั้งแต่ 8 ปีขึ้นไปและบุคคลที่มีข้อจำกัดทางร่างกาย ระบบประสาท หรือสภาวะจิต หรือขาดประสบการณ์และความรู้ ล้วนแต่สามารถใช้เครื่องใช้ไฟฟ้านี้ได้ แต่ต้องได้รับการควบคุมดูแลหรือชี้แนะวิธีใช้งานเครื่องอย่างปลอดภัยและเข้าใจถึงอันตรายที่อาจเกิดขึ้นจากการใช้เครื่อง
- เด็กๆ ไม่ควรเล่นเครื่อง ไม่ควรปล่อยให้เด็กทำความสะอาดและบำรุงรักษาเครื่องโดยไม่มีการควบคุมดูแล
- ตรวจสอบให้แน่ใจว่าคุณได้ปิดเครื่องฟอกอากาศและถอดปลั๊กออกแล้วก่อนที่จะทำการบำรุงรักษา ยึดตะแกรงโดยใช้สกรูหลังจากทำความสะอาดใบพัดและห่อลม

ข้อพึงระวังเพื่อความปลอดภัย


การเคลื่อนย้าย	· ปิดและถอดปลั๊กเครื่องฟอกอากาศก่อนที่จะทำการเคลื่อนย้าย
การติดตั้ง	· คุณจะไม่สามารถเปิดเครื่องฟอกอากาศได้หากไม่มีการติดตั้งตะแกรงพัดลมและฝาปิดไส้กรองเครื่องฟอกอากาศอย่างเหมาะสม · รักษาระยะห่างอย่างน้อย 20 ซม. ระหว่างช่องรับอากาศกับกำแพงหรือสิ่งอื่นๆ
การทำความสะอาด	· ก่อนทำความสะอาดหรือทำการบำรุงรักษาอื่นๆ ต้องถอดปลั๊กเครื่องออกจากแหล่งจ่ายไฟ · กำจัดฝุ่น เส้นผมและฝุ่นละอองต่างๆ ออกจากตะแกรงกรองด้านนอกของไส้กรองเครื่องฟอกอากาศอย่างสม่ำเสมอเพื่อลดโอกาสในการเกิดแบคทีเรีย · กำจัดฝุ่น เส้นผมและฝุ่นละอองต่างๆ ออกจากช่องรับอากาศของเครื่องฟอกอากาศเพื่อป้องกันการลดลงของปริมาณอากาศเข้า · ปิดช่องระบายอากาศเพื่อป้องกันไม่ให้ฝุ่น เส้นผมและฝุ่นละอองต่างๆ เข้าไปข้างในเมื่อไม่มีการใช้งานเครื่องฟอกอากาศเป็นเวลานาน
แหล่งจ่ายไฟ	เพื่อหลีกเลี่ยงไม่ให้เกิดไฟไหม้ ไฟดูดหรือความเสียหายอื่นๆ การใช้สายไฟและแหล่งจ่ายไฟตามคำแนะนำไว้ดังต่อไปนี้เท่านั้น: · ห้ามดึง บิดหรือของสายไฟมากเกินไปเนื่องจากอาจทำให้สัมผัสหรือทำให้แกนสายไฟเสียหายได้ · เสียบสายไฟเข้าไปในแหล่งจ่ายไฟฟ้าที่เหมาะสมเท่านั้น · ใช้สายไฟที่ได้รับมาพร้อมกับเครื่องฟอกอากาศเท่านั้น ห้ามใช้สายไฟของบริษัทผู้ผลิตรายอื่น · ถอดปลั๊กออกจากเครื่องฟอกอากาศก่อนที่จะทำการบำรุงรักษาหรือเคลื่อนย้ายเครื่องฟอกอากาศอยู่เสมอ
ระหว่างการใช้งาน	· หยุดใช้งานเครื่องฟอกอากาศทันทีเมื่อเครื่องฟอกอากาศมีเสียงที่ผิดปกติ สั่นกั่นเหม็น ร้อนจัดหรือเมื่อพัดลมหมุนผิดปกติ · ห้ามเหยียบย่ำของคุณหรือสิ่งแปลกปลอมต่างๆ เข้าไปในส่วนที่มีการป้องกัน ส่วนที่เคลื่อนไหว ช่องรับอากาศหรือช่องระบายอากาศ · กันไม่ให้วัตถุต่างๆ เช่น เส้นผมหรือเส้นใยยูกิปลั๊กเครื่องฟอกอากาศเพื่อป้องกันการอุดตันของช่องรับอากาศหรือช่องระบายอากาศ · อย่างน้อยที่สุด ฟัง หรือตรวจสอบเครื่องฟอกอากาศ · เมื่อใช้งานร่วมกับอุปกรณ์ที่ใช้แก๊สและน้ำมัน (เช่น เตาแก๊ส เครื่องทำความร้อนแบบใช้แก๊ส) โปรดระมัดระวังการปล่อยแก๊สคาร์บอนมอนอกไซด์เป็นพิษ · ห้ามแขวนของเหลวหรือสิ่งของสารชนิดต่างๆ เข้าไปในช่องระบายอากาศของเครื่องฟอกอากาศ
ข้อจำกัดในการใช้งาน	ห้ามใช้งานเครื่องฟอกอากาศในสภาพการดังต่อไปนี้เนื่องจากอาจก่อให้เกิดไฟดูด ไฟไหม้หรือความเสียหายอื่นๆ ได้: · ใกล้เปลวไฟ เช่น เหยือกไข กระถางธูป เตาไฟ เตาแก๊ส บุหรี่ ประทัด เครื่องจุดไฟ ธูปไฟ ที่จุดเทียน หรือแหล่งติดไฟต่างๆ · ใกล้อุปกรณ์ต่างๆ ที่ก่อให้เกิดอุณหภูมิสูง เช่น เครื่องทำความร้อนไฟฟ้า เครื่องทำความร้อนพัดลม เครื่องทำความร้อนสำหรับเตาเตาไฟฟ้า เตาไรต์ไฟ · ตรวจสอบให้แน่ใจว่า ไม่มีวัตถุไวไฟเข้าไปในเครื่องฟอกอากาศ · ในตำแหน่งที่ไม่เหมาะสมซึ่งเครื่องฟอกอากาศอาจล้มคว่ำลงมาได้ง่าย · ในสภาพแวดล้อมที่ร้อน ชื้นและหม่นมืดมาก เช่น ห้องน้ำ

ภาพรวมผลิตภัณฑ์

อ่านคู่มือฉบับนี้ให้ละเอียดก่อนใช้งาน และดาราเก็บไว้ใช้อ้างอิงในอนาคต
หมายเหตุ: ภาพของผลิตภัณฑ์ อุปกรณ์เสริมและยูสเซอร์อินเตอร์เฟซในคู่มือการใช้งานใช้สำหรับการอ้างอิงเท่านั้น
ผลิตภัณฑ์และฟังก์ชันการทำงานจริงอาจแตกต่างกันไปเนื่องจากการปรับปรุงผลิตภัณฑ์




มุมมองด้านหน้า



มุมมองด้านหลัง

ภาพรวมผลิตภัณฑ์

คำแนะนำการใช้งานหน้าจอ




ฟังก์ชันโอโซนประจุลบจะถูกเปิดใช้งานตามค่าเริ่มต้น ตัวเครื่องจะปล่อยโอโซนประจุลบระหว่างการทำงานโอโซนอากาศประจุลบ (NAI) จะถูกสร้างขึ้นจากปฏิกิริยาระหว่างอิเล็กตรอนประจุลบกับโมเลกุลของออกซิเจน NAI สามารถดักจับมลพิษทางอากาศบางประเภทได้อย่างยอดเยี่ยม สามารถเปิดหรือปิดฟังก์ชันนี้ในแอปได้ เมื่อเปิดใช้งานไฟแสดงสถานะโอโซนประจุลบจะสว่างเมื่อปิดใช้งาน ไฟแสดงสถานะโอโซนประจุลบจะดับ

การติดตั้ง


การวางเครื่องฟอกอากาศ

เพื่อประสิทธิภาพสูงสุด ควรตรวจสอบให้แน่ใจว่าระยะห่างระหว่างช่องลมเข้าของเครื่องฟอกอากาศกับวัตถุต่างๆ อาทิ ผนัง ตรงตามข้อกำหนดตามที่แนะนำที่ด้านล่าง



การเชื่อมต่อเข้ากับเต้ารับไฟฟ้า

เชื่อมต่อสายไฟเข้ากับพอร์ตจ่ายไฟที่ด้านล่างของเครื่องฟอกอากาศ จากนั้นจึงเสียบปลั๊กเข้าไปในเต้ารับไฟฟ้า



หมายเหตุ: แนะนำให้เปิดประตูและหน้าต่างระหว่างที่ใช้งานเครื่องฟอกอากาศเพื่อการฟอกอากาศที่มีประสิทธิภาพยิ่งขึ้น

วิธีการใช้

การเปิด/ปิดเครื่อง

แต่ถ้าไม่เปิดเครื่องเพื่อเปิดเครื่องฟอกอากาศในขณะที่เครื่องฟอกอากาศเปิดอยู่ให้คุณแต่ที่ปุ่มเปิดปิดเครื่องเพื่อปิดเครื่องฟอกอากาศ



การสลับโหมด

ในขณะที่เครื่องฟอกอากาศเปิดอยู่ให้คุณแต่ที่ปุ่มสลับโหมดเพื่อสลับเป็นโหมดต่างๆ



การแจ้งเตือนอายุการใช้งานของไส้กรองเครื่องฟอกอากาศ

หน้าจอจะแสดงระยะเวลาการใช้งานที่เหลือของไส้กรองเครื่องฟอกอากาศ เมื่อคุณเปิดเครื่องฟอกอากาศหน้าจอจะแสดงไอคอนคำเตือนหากตรวจพบไส้กรองเครื่องฟอกอากาศที่ไม่ใช่ของแท้



การแจ้งเตือนระยะเวลาการใช้งานที่เหลือของไส้กรองเครื่องฟอกอากาศ




คำเตือนไส้กรองเครื่องฟอกอากาศไม่ใช่ของแท้

การปรับความสว่างของหน้าจอ

กดปุ่มเปิด/ปิดหน้าจอเพื่อสลับระดับความสว่างของหน้าจอ: สว่าง สกัว ดับ

การใช้เน็ต Wi-Fi

เมื่อเชื่อมต่อเครื่องฟอกอากาศเข้ากับแอปเป็นครั้งแรกหรือเมื่อไม่สามารถเชื่อมต่อเข้ากับแอปได้ให้คุณกดปุ่มเปิด/ปิดหน้าจอค้างไว้เป็นเวลา 7 วินาที เครื่องฟอกอากาศจะส่งเสียงการแจ้งเตือนเมื่อ Wi-Fi ได้รับการเชื่อมต่อเรียบร้อยแล้ว




การเปิดใช้งาน/การปิดใช้งานฟังก์ชันล็อกป้องกันเด็ก

กดปุ่มสลับโหมดเป็นเวลา 7 วินาทีเพื่อเปิดใช้งานหรือปิดใช้งานฟังก์ชันล็อกป้องกันเด็ก เครื่องฟอกอากาศจะส่งเสียงการแจ้งเตือนที่กึ่งยาวซิ่ง และแสดงไอคอนที่กึ่งยาวซิ่งบนหน้าจอ

วิธีการใช้

การเปิดใช้งาน/การปิดใช้งาน Wi-Fi

กดปุ่มสับโหมดบนหน้าจอและปุ่มปรับความสว่างค้างไว้พร้อมกันเป็นเวลา 7 วินาที เครื่องฟอกอากาศจะส่งเสียงการแจ้งเตือน และ Wi-Fi จะถูกปิดใช้งานในขณะที่ยังเปิด Wi-Fi อยู่ให้คุณกดปุ่มสับโหมดบนหน้าจอและปุ่มปรับความสว่างค้างไว้พร้อมกันเป็นเวลา 7 วินาที เครื่องฟอกอากาศจะส่งเสียงการแจ้งเตือน และ Wi-Fi จะถูกเปิดใช้งาน



สามารถเชื่อมต่อกับแอป Mi Home/Xiaomi Home

ผลิตภัณฑ์นี้ทำงานกับแอป Mi Home/Xiaomi Home* ได้ ใช้แอป Mi Home/Xiaomi Home ดาบลูกมูอุปกรณ์และเชื่อมต่อกับอุปกรณ์ Smart home อื่นๆ

สมมติว่าผู้ใช้ติดตั้งตามขั้นตอนและติดตั้งแอป ระบบจะนำคุณไปที่หน้าการตั้งค่าการเชื่อมต่อ หากแอปได้รับการติดตั้งแล้ว หรือค้นหา "Mi Home/Xiaomi Home" ใน App Store เพื่อดาวน์โหลดและติดตั้งแอป เปิดแอป Mi Home/Xiaomi Home แล้วแตะ "+" ที่ด้านซ้ายบน จากนั้นไปที่ปฏิบัติตามพร้อมรหัสที่เพิ่มอุปกรณ์ของคุณ * แอปนี้ถูกเรียกว่าแอป Xiaomi Home ในยุโรป (ยกเว้นในรัสเซีย) ชื่อแอปที่แสดงบนอุปกรณ์ของคุณจะถือว่าเป็นค่าเริ่มต้น



A4E9BC43


หมายเหตุ: เวอร์ชันของแอปอาจไม่ตรงเท่ากับรุ่นปฏิบัติการตามคำแนะนำตามเวอร์ชันปัจจุบันของแอป

การดูแลและการบำรุงรักษา

⚠ คำเตือน: ตรวจสอบให้แน่ใจว่าคุณได้ปิดเครื่องฟอกอากาศและถอดปลั๊กออกแล้วก่อนที่จะดำเนินการดังต่อไปนี้

การทำความสะอาดใบพัดและห่อลม

- ถอดรอบภายนอกฝาปิดเพื่อเปิดฝาปิด ใช้ไขควงคลายสกรู จากนั้นจึงดึงฝาปิดขึ้นด้านบนเพื่อถอดตะแกรงออก
- ใช้เครื่องดูดฝุ่นกำจัดฝุ่นและของออกจากห่อลมและใบพัด หรือค่อยๆ เช็ดฝุ่นและของออกโดยใช้ผ้านุ่มๆ
- ใช้แปรงหรือผ้านุ่มๆ ค่อยๆ เช็ดห่อลมสมิตเตอร์ประจุลบ
- ใส่ตะแกรงกลับเข้าไป และขันสกรูให้แน่นหลังจากทำความสะอาด หมายเหตุ: เพื่อหลีกเลี่ยงการสูญหาย สกรูจึงถอดออกไม่ได้ คลายสกรูเพื่อถอดตะแกรงออก




หมายเหตุ: เพื่อหลีกเลี่ยงการทำให้อุปกรณ์ฟอกอากาศเสียหาย ห้ามล้างหรือฉีดห่อลมและใบพัดโดยตรงด้วยน้ำ หรือเช็ดห่อลมและใบพัดด้วยผ้าที่เปียกชื้น

การดูแลและการบำรุงรักษา

การทำความสะอาดช่องใส่กรองเครื่องฟอกอากาศ


เพื่อให้แน่ใจได้ถึงการระบายอากาศและการฟอกอากาศที่ดีที่สุด คุณควาใช้เครื่องดูดฝุ่นในการกำจัดฝุ่นละอองจากช่องลมเข้าและช่องใส่กรองเครื่องฟอกอากาศ หรือตอวยู เช็ดบริเวณดังกล่าวโดยใช้น้ำอุ่นๆ



หมายเหตุ: เพื่อหลีกเลี่ยงการทำให้เครื่องฟอกอากาศเสียหาย ห้ามล้างหรือฉีดช่องใส่กรองเครื่องฟอกอากาศโดยตรงโดยใช้น้ำ หรือฉีดช่องใส่ใส่ใส่กรองอากาศโดยใช้น้ำที่เปียกโชก

การทำความสะอาดเซ็นเซอร์ตรวจจับอนุภาคด้วยเลเซอร์

ใช้เครื่องมือที่ไม่คมเปิดฝเปิดช่องเซ็นเซอร์ตรวจจับอนุภาคด้วยเลเซอร์ จากนั้นใช้ปืนเป่าลมหรือไดร์เป่าผมทำความสะอาดไส้กรองเครื่องฟอกอากาศบนฝาปิดและเซ็นเซอร์ตามที่แสดงในรูปแบบ



หมายเหตุ: ห้ามใช้สิกร้อน

ข้อมูลจำเพาะ

ชื่อ : เครื่องฟอกอากาศอัจฉริยะ Xiaomi 4

รุ่น : AC-M16-SC

ขนาด : 250 × 250 × 555 มม.

น้ำหนักสุทธิ : ประมาณ 5.6 กก.

ครอบคลุมพื้นที่ : 28-48 ตร.ม.

แรงดันไฟฟ้า : 100-240V~

ความถี่ : 50/60Hz

กำลังไฟฟ้า : 30W

ระดับเสียง : ≤64dB(A)

การใช้พลังงานระหว่างที่เครื่องช่วยสแตนด์บาย : < 2.0 W

ประสิทธิภาพการฟอกอากาศอนุภาค : สูง

ประสิทธิภาพการฟอกอากาศของฟอร์มาลดีไฮด์ : สูง

อัตราการส่งผ่านอากาศบริสุทธิ์ของอนุภาค (CADR ของอนุภาค) : 400 ลบ.ม./ชม.

อัตราการส่งผ่านอากาศบริสุทธิ์ของฟอร์มาลดีไฮด์ (CADR ของฟอร์มาลดีไฮด์) : 150 ลบ.ม./ชม.

การเชื่อมต่อแบบไร้สาย : Wi-Fi IEEE 802.11b/g/n 2.4GHz

เครื่องโทรทัศน์และอุปกรณ์อื่น ๆ ไม่ควมสอดคล้องตามมาตรฐานหรือข้อกำหนดทางเทคนิคของ กสทช.

WARNING

- When the power cord is damaged, it must be replaced with a genuine power cord purchased from the manufacturer or after-sales service department.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Make sure the purifier is turned off and unplugged before performing the maintenance. Fix the grille with screw after cleaning fan blades and air duct.

Precautions

· Turn off and unplug the purifier before moving it.

· The purifier cannot turn on when the fan grille and the filter compartment cover are not installed properly.

· Maintain a distance of at least 20 cm between the air inlets and walls or other objects.

· The purifier must be placed on firm and flat floor.

· Prior to cleaning or other maintenance, the appliance must be disconnected from the supply mains.

· Frequently remove dust, hair, and other particles from the outer mesh screen of the filter, so as to reduce the chance of bacteria growth.

· Remove dust, hair, and particles from the purifier's air inlets to prevent a reduction of air intake.

· Cover the air outlet to prevent dust, hair, and other particles from falling in when the purifier is left unused for a long time.

To avoid fire, electric shocks, or other damage, use the power cord and electrical outlet as instructed below:

· Do not excessively pull, twist or bend the power cord, as this may expose or break the cord's core.

· The power cord must be plugged into a suitable electrical outlet.

· Use the power cord that is provided with the purifier, do not use any third party power cords.

· Always unplug the purifier before carrying out maintenance to or moving the air purifier.

· Immediately stop using the purifier when it makes unusual sounds, gives off bad odors, overheats, or its fan rotates irregularly.

· Do not stick your fingers or foreign objects into the protective parts, movable parts, air inlets, or air outlets.

· Keep objects such as hairs or fabrics away from the purifier to avoid blocking the air inlets or air outlets.

· Do not sit on, lean on or tilt the purifier.

· When using in conjunction with gas-fueled appliances (such as gas stoves, gas heaters), please ventilate sufficiently to avoid carbon monoxide poisoning.

· Do not pour liquids, nor throw powders or other small substances into the purifier's air outlet.

Do not use the purifier in the following circumstances, as they may result in electric shocks, fire, or other damage:

· Near open flames, such as candles, incense burners, stoves, fireplaces, cigarettes, firecrackers, lighters, multipurpose torches, candle lighters, or fire pans.

· Near appliances that generate high temperatures, such as electric heaters, fan heaters, electric foot warmers, electric stoves, or electric irons.

· Make sure no inflammable objects get into the purifier.


· In unstable locations where the purifier can easily fall over.

· In environments that are extremely hot, humid, or damp, such as bathrooms.


Product Overview

Read this manual carefully before use, and retain it for future reference.

Note: Illustrations of the product, accessories, and user interface in this user manual are for reference purposes only. The actual product and functions may vary due to product enhancements.




Front View



Rear View

Product Overview

Display Instructions




The negative ion function is enabled by default. The purifier can generate negative ions when it is working, and then the negative air ions (NAI) are produced through the reaction between the negative electron and the oxygen molecules. NAI is very good at trapping certain air pollutants. The function can be enabled or disabled in the app. When it is enabled, the negative ion indicator is on; when it is disabled, the indicator is off.

Installation


Placing the purifier

For optimal performance, make sure the distances between purifier's air inlets and other objects such as walls meet the requirements as suggested below.



Connecting to an electrical outlet

Connect the power cord to the power port at the bottom of the purifier and then plug it into an electrical outlet.



Note: It is recommended to keep doors and windows closed for a better purifying effect when using the purifier.

How to Use

Turning on/off

Tap the power button to turn on the purifier.

While the purifier is on, tap the power button to turn it off.



Switching mode

While the purifier is on, tap the mode switch button to cycle through modes.




Adjusting the display's brightness

Press the display on/off button to cycle through its brightness levels: on, dim, and off.

Resetting Wi-Fi

When connecting the purifier to the app for the first time or unable to connect to it, press and hold the display on/off button for 7 seconds. The purifier will make a notification sound once Wi-Fi is successfully reset.



Filter life notification

The display will show the remaining service time of the filter when the purifier is turned on.

The display will show a warning icon if no genuine filter is detected.



Filter service time remaining notification



Not a genuine filter warning

Enabling/disabling the child lock function


Press and hold the mode switch button for 7 seconds to enable or disable the child lock function. The purifier will make the corresponding notification sound and show the corresponding icon on the display.

How to Use

Enabling/Disabling Wi-Fi

Simultaneously press and hold the mode switch button on the display and the brightness adjustment button for 7 seconds. The purifier will make a notification sound and the Wi-Fi will be disabled.

While Wi-Fi is off, simultaneously press and hold the mode switch button on the display and the brightness adjustment button for 7 seconds. The purifier will make a notification sound and the Wi-Fi will be enabled.



Connect with Mi Home / Xiaomi Home App

This product works with Mi Home / Xiaomi Home app*. Control your device with Mi Home / Xiaomi Home app.



A4E9BC43

Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search "Mi Home / Xiaomi Home" in the app Store to download and install it.

Open Mi Home / Xiaomi Home app, tap "+" on the upper right, and then follow prompts to add your device.

*The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.

Note: The version of Mi Home app might have been updated, please follow the instructions based on the current app version.


Daily Care & Maintenance

Warning: Make sure the purifier is turned off and unplugged before performing the following operations.

Cleaning fan blades and air duct

- Press the indentation on the cover to open it. Use a screwdriver to loosen the screw, and then pull the cover upwards to remove the grille.
- Use a vacuum cleaner to remove any dust from the air duct and fan blades, or wipe the dust off gently with a soft cloth.
- Use a brush or soft cloth to gently wipe the negative ion transmitter.
- Install the grille back and fasten the screw after cleaning.

Note: To avoid missing, the screw is not removable. Loosen the screw to remove the grille.




Negative Ion Transmitter

Note: To avoid damaging the purifier, do not rinse or spray the air duct and fan blades directly with water, or wipe them with a soaking wet cloth.

Daily Care & Maintenance

Cleaning the filter compartment


To ensure optimal ventilation and purification, use a vacuum cleaner to remove any dust from the air inlets and the filter compartment, or wipe these areas gently with a soft cloth.



Note: To avoid damaging the purifier, do not rinse or spray the filter compartment directly with water, or wipe it with a soaking wet cloth.

Cleaning the laser particle sensor

Use a non-sharp tool to open the cover of the laser particle sensor, then use an air blow gun or hair dryer to clean the filter on the cover and the sensor, as illustrated in the figure.



Note: Do not use hot air.

Specifications

Name: Xiaomi Smart Air Purifier 4
Model: AC-M16-SC
Item Dimensions: 250 × 250 × 555 mm
Net Weight: Approx. 5.6 kg
Effective Coverage: 28–48 m²
Rated Voltage: 100–240 V~
Rated Frequency: 50/60 Hz
Rated Power: 30 W
Noise Level: ≤64 dB(A)

Network Standby Power Consumption: < 2.0 W
Particle Purification Efficiency: High
Formaldehyde Purification Efficiency: High
Particle's Clean Air Delivery Rate (CADR Particle): 400 m³/h
Formaldehyde's Clean Air Delivery Rate (CADR Formaldehyde): 150 m³/h
Wireless Connectivity: Wi-Fi IEEE 802.11 b/g/n 2.4 GHz
Storage Temperature: -10°C to 40°C
Storage Humidity: 5%–90%
Production Date: See packaging
For details of the importer, please refer to the box.

RF Specification:
Wi-Fi 2.4 G (2400–2483.5 MHz), Max. RF Output Power: <20 dBm
RFID (13.56 MHz), Max. Magnetic Field Strength: <60 dBμA/m@10 m
Under normal use of condition, this equipment should be kept a separation distance of at least 20cm between the antenna and the body of the user.

Regulatory Compliance Information

Disposal and recycling information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

การรับประกันสินค้า

การรับประกันเป็นสิทธิพิเศษเฉพาะเจาะจงแก่คุณ และคุณอาจมีสิทธิอื่นๆ ตามกฎหมายของประเทศ มลรัฐ หรือรัฐของคุณ แน่นอนว่า ในบางประเทศ มลรัฐ หรือรัฐ กฎหมายผู้บริโภคอาจกำหนดระยะเวลาการรับประกันขั้นต่ำ นอกเหนือจากที่ได้ระบุอนุญาตตามกฎหมาย XIAOMI จะไม่ยกเว้น จำกัด หรือระงับสิทธิอื่นๆ ที่คุณอาจมี เพื่อตามเข้าใจสิทธิของคุณอย่างถ่องแท้ เราขอเชิญให้คุณค้นคว้ากฎหมายของประเทศ มลรัฐ หรือรัฐของคุณ

1.การรับประกันสินค้าแบบจำกัด

XIAOMI รับประกันว่าผลิตภัณฑ์ปราศจากข้อบกพร่องด้าน วัสดุและคุณภาพ ภายใต้การใช้งานปกติและการใช้งานตามคู่มือผู้ใช้ผลิตภัณฑ์ที่เกี่ยวข้อง ในระยะเวลาการรับประกันระยะเวลาและเงื่อนไขที่เกี่ยวข้องกับการรับประกันตามกฎหมายจะทำให้ได้ตามกฎหมายในประเทศของคุณตามลำดับ สำหรับข้อมูลเพิ่มเติมเกี่ยวกับประโยชน์จากการรับประกันสำหรับผู้บริโภค โปรดดูที่เว็บไซต์ทางการของ Xiaomi <https://www.mi.com/global/service/warranty/> Xiaomi รับประกันต่อผู้ซื้อผลิตภัณฑ์ครั้งแรกว่าผลิตภัณฑ์ Xiaomi จะไม่มีข้อบกพร่องด้าน วัสดุและคุณภาพภายใต้การใช้งานปกติในระยะเวลาตามที่กล่าวไว้ด้านบน Xiaomi ไม่รับประกันว่าการใช้งานของผลิตภัณฑ์จะไม่ถูกรบกวนหรือปราศจากข้อผิดพลาด Xiaomi ไม่มีส่วนรับผิดชอบต่อความเสียหายที่เกิดขึ้นจากการไม่ปฏิบัติตามคำแนะนำที่เกี่ยวข้องกับการใช้ผลิตภัณฑ์

2.การขยายยา

หากพบข้อบกพร่องด้านฮาร์ดแวร์และ Xiaomi ได้รับการอ้างสิทธิ์ที่ถูกต้องภายในระยะเวลาประกัน Xiaomi จะ (1) ซ่อมแซมผลิตภัณฑ์ที่ไม่มีค่าใช้จ่าย (2) เปลี่ยนผลิตภัณฑ์ หรือ (3) คืนเงินค่าผลิตภัณฑ์ โดยไม่รวมค่าจัดส่งที่อาจเกิดขึ้น

3.วิธีรับบริการการรับประกัน

ในการรับบริการการรับประกัน คุณต้องส่งผลิตภัณฑ์ในบรรจุภัณฑ์ดั้งเดิม หรือบรรจุภัณฑ์ที่คล้ายคลึงและปกป้องผลิตภัณฑ์ได้เท่าเทียมกัน มายังที่อยู่ระบุไว้โดย Xiaomi เท่านั้น แต่ในบางเขตที่ตั้งตามตามกฎหมายที่ยังคงใช้ Xiaomi อาจเรียกร้องให้คุณแสดงหลักฐานหรือหลักฐานการซื้อ และ/หรือปฏิบัติตามข้อกำหนดการลงทะเบียนก่อนเริ่มบริการการรับประกัน

4.ข้อบกพร่องและข้อจำกัด

เร้าแต่ได้กำหนดไว้เป็นข้อบังคับโดย Xiaomi การรับประกันแบบจำกัดนี้ไม่ครอบคลุมผลิตภัณฑ์ที่ผลิตโดยหรือเพื่อ Xiaomi และสามารถระบุได้โดยเครื่องหมายการค้า ชื่อการค้า หรือโลโก้ "Xiaomi" หรือ "Mi" เท่านั้น การรับประกันแบบจำกัดไม่มีผลต่อ (ก) ความเสียหายที่เกิดจากธรรมชาติหรือเหตุสุดวิสัย ตัวอย่างเช่น ไฟป่า ฮอร์เน็ต น้ำท่วม ไฟไหม้ แผ่นดินไหว หรือเหตุภัยแล้งอื่นๆ (ข) ความประมาทเห็นแก่ตัว (ค) การใช้ผิดการค้า (ง) การปรับเปลี่ยนหรือแก้ไขส่วนใดส่วนหนึ่งของผลิตภัณฑ์ (จ) ความเสียหายที่เกิดจากการใช้งานที่ไม่ถูกต้องของผลิตภัณฑ์ที่ไม่ใช่ของ Xiaomi (ฉ) ความเสียหายที่เกิดจากอุบัติเหตุ การละเมิด หรือการใช้งานที่ผิด (ช) ความเสียหายที่เกิดจากการใช้งานผลิตภัณฑ์นอกเหนือจากที่ได้ระบุอนุญาตหรือเหนือวัตถุประสงค์ที่อธิบายไว้โดย Xiaomi หรือใช้แรงดันไฟฟ้าหรือแหล่งจ่ายไฟที่ไม่เหมาะสม หรือ (ซ) ความเสียหายที่เกิดจากการบริการ (รวมถึงการวินิจฉัยและการขยาย) ที่ดำเนินการโดยผู้ที่ไม่ใช่ตัวแทนของ Xiaomi การสำรองข้อมูล ซอฟต์แวร์ หรือ วัสดุอื่นใดที่คุณอาจเก็บหรือรักษาไว้ในผลิตภัณฑ์ อยู่ในความรับผิดชอบของคุณ มีแนวโน้มว่าข้อมูล ซอฟต์แวร์ หรือ วัสดุอื่นใดในอุปกรณ์จะสูญหายหรือถูกจัดรูปแบบใหม่ในระหว่างกระบวนการให้บริการ Xiaomi จะไม่รับผิดชอบต่อความเสียหายหรือความสูญเสียดังกล่าว ไม่มีผู้รับประกัน ตัวแทน หรือพนักงานของ Xiaomi ได้รับอนุญาตให้แก้ไข ซ่อม หรือเพิ่มเติมใดๆ นอกเหนือการรับประกันแบบจำกัดนี้ หากข้อกำหนดใดๆ

ผิดต่อกฎหมายหรือไม่สามารถบังคับใช้ได้ ความชอบด้วยกฎหมายหรือการบังคับใช้ข้อกำหนดเหล่านี้จะไม่ได้เป็นผลกระทบหรือความเสื่อมเสีย
กับการรับประกันที่ให้แก่โดยกฎหมาย หรือสัญญาไว้โดย Xiaomi บริการหลังการขายจะจำกัดตามประเทศหรือภูมิภาคของการซื้อผลิตภัณฑ์ครั้งแรก
ผลิตภัณฑ์ที่ไม่ได้รับการนำเข้าอย่างถูกต้องและ/หรือไม่ได้ผลิตอย่างถูกต้องโดย Xiaomi และ/หรือไม่ได้รับมาอย่างถูกต้องจาก Xiaomi หรือผู้ขายอย่าง
เป็นทางการของ Xiaomi จะไม่ได้รับความคุ้มครองตามการรับประกันปัจจุบัน ตามกฎหมายที่ยังคงใช้ คุณอาจได้รับประโยชน์จากการรับประกัน
จากผู้ถือครองปัจจัยไม่มีเป็นทางการที่ขายผลิตภัณฑ์ ดังนั้น Xiaomi ขอแนะนำให้คุณติดต่อผู้ขายปลีกที่คุณซื้อผลิตภัณฑ์

5. การรับประกันโดยนัย

เว้นแต่ในขอบเขตที่ต้องห้ามตามกฎหมายที่บังคับใช้ การรับประกันโดยนัยทั้งหมด (รวมถึงการรับประกันสภาพการันตีประโยชน์ในเชิงพาณิชย์และ
ความเหมาะสมสำหรับวัตถุประสงค์เฉพาะ) จะมีระยะเวลาจำกัดจนถึงระยะเวลาสูงสุดของการรับประกันแบบจำกัดนี้ เซกส์ทางศาลบางแห่งไม่
อนุญาตให้มีข้อจำกัดเกี่ยวกับระยะเวลาการรับประกันโดยนัย ดังนั้นข้อจำกัดข้างต้น จะไม่ถูกนำมาใช้ในกรณีเหล่านั้น

6. ข้อจำกัดความเสียหาย

เว้นแต่ในขอบเขตที่ต้องห้ามตามกฎหมายที่บังคับใช้ Xiaomi จะไม่มีผิดชอบต่อความเสียหายใดๆ ที่เกิดขึ้นจากอุบัติเหตุ ความเสียหายโดยอ้อม
ความเสียหายพิเศษหรือความเสียหายที่เกิดตามมา รวมถึงแต่ไม่จำกัดเพียงการสูญเสียผลกำไร รายได้หรือข้อมูล ความเสียหายที่เป็นผลมาจากการ
ละเมิดเงื่อนไขการรับประกันที่ขัดแย้งหรือโดยนัยหรือภายใต้กฎหมายใดก็ตาม แม้ว่า Xiaomi จะได้รับแจ้งถึงความเป็นไปได้ในการเกิด
ความเสียหายดังกล่าวก็ตาม เซกส์ทางศาลบางแห่งไม่อนุญาตให้มีข้อบกพร่องหรือข้อจำกัดความเสียหายพิเศษ ความเสียหายโดยอ้อม หรือความ
เสียหายที่เกิดตามมา ดังนั้นข้อจำกัดหรือข้อบกพร่องด้านบนอาจไม่มีผลกับคุณ

7. ติดต่อ XIAOMI

สำหรับลูกค้า โปรดเยี่ยมชมเว็บไซต์: <https://www.mi.com/global/service/warranty/>

ผู้ติดต่อสำหรับบริการหลังการขายอาจเป็นบุคคลใดก็ได้ในเครือข่ายการให้บริการที่ได้รับอนุญาตจาก Xiaomi ผู้แทนจำหน่ายที่ได้รับอนุญาตจาก Xiaomi หรือผู้จำหน่าย
ชั้นสุดท้ายที่ขายผลิตภัณฑ์ให้คุณ หากมีข้อสงสัย โปรดติดต่อบุคคลที่เกี่ยวข้องที่ Xiaomi อาจระบุด้วยบุคคลได้

WARRANTY NOTICE

THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY HAVE OTHER RIGHTS CONVEYED BY LAWS OF YOUR COUNTRY, PROVINCE OR STATE. INDEED, IN SOME COUNTRIES, PROVINCES OR STATES, CONSUMER LAW MAY IMPOSE A MINIMUM WARRANTY PERIOD. OTHER THAN AS PERMITTED BY LAW, XIAOMI DOES NOT EXCLUDE, LIMIT OR SUSPEND OTHER RIGHTS YOU MAY HAVE. FOR A FULL UNDERSTANDING OF YOUR RIGHTS WE INVITE YOU TO CONSULT THE LAWS OF YOUR COUNTRY, PROVINCE OR STATE.

1.LIMITED PRODUCT WARRANTY

XIAOMI warrants that the Products are free from defects in materials and workmanship under normal use and use in accordance with the respective Product user manual, during the Warranty Period.

The duration and conditions related to the legal warranties are provided by respective local laws. For more information about the consumer warranty benefits, please refer to Xiaomi's official website <https://www.mi.com/global/service/warranty/>.

Xiaomi warrants to the original purchaser that its Xiaomi Product will be free from defects in materials and workmanship under normal use in the period mentioned above.

Xiaomi does not guarantee that the operation of the Product will be uninterrupted or error free.

Xiaomi is not liable for damages arising from non-compliance with the instructions related to the use of the Product.

2.REMEDIES

If a hardware defect is found and a valid claim is received by Xiaomi within the Warranty Period, Xiaomi will either (1) repair the product at no charge, (2) replace the product, or (3) refund the Product, excluding potential shipping costs.

3.HOW TO OBTAIN WARRANTY SERVICE

To obtain warranty service, you must deliver the Product, in its original packaging or similar packaging providing an equal degree of Product protection, to the address specified by Xiaomi. Except to the extent prohibited by applicable law, Xiaomi may require you to present proofs or proof of purchase and / or comply with registration requirements before receiving warranty service.

4.EXCLUSIONS AND LIMITATIONS

Unless otherwise stipulated by Xiaomi, this Limited Warranty applies only to the Product manufactured by or for Xiaomi and identifiable by the trademarks, trade name or "Xiaomi" or "Mi" logo.

The Limited Warranty does not apply to any (a) Damage due to acts of nature or God, for example, lightning strikes, tornadoes, flood, fire, earthquake or other external causes; (b) Negligence; (c) Commercial use; (d) Alterations or modifications to any part of the Product; (e) Damage caused by use with non-Xiaomi products; (f) Damage caused by accident, abuse or misuse; (g) Damage caused by operating the Product outside the permitted or intended uses described by Xiaomi or with improper voltage or power supply; or (h) Damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of Xiaomi.

It is your responsibility to backup any data, software, or other materials you may have stored or preserved on the product. It is likely that the data, software or other materials in the equipment will be lost or reformatted during the service process, Xiaomi is not responsible for such damage or loss.

No Xiaomi reseller, agent, or employee is authorized to make any modification, extension, or addition to this Limited Warranty. If any term is held to be illegal or unenforceable, the legality or enforceability of the remaining terms shall not be affected or impaired.

Except as prohibited by laws or otherwise promised by Xiaomi, the after-sales services shall be limited to the country or region of the original purchase.

Products which were not duly imported and/or were not duly manufactured by Xiaomi and/or were not duly acquired from Xiaomi or a Xiaomi's official seller are not covered by the present warranties. As per applicable law you may benefit from warranties from the non-official retailer who sold the product. Therefore, Xiaomi invites you to contact the retailer from whom you purchased the product.

5.IMPLIED WARRANTIES

Except to the extent prohibited by applicable law, all implied warranties (including warranties of merchantability and fitness for a particular purpose) will have a limited duration up to a maximum duration of this limited warranty. Some jurisdictions do not allow limitations on the duration of an implied warranty, so the above limitation will not be applied in these cases.

6.DAMAGE LIMITATION

Except to the extent prohibited by applicable law, Xiaomi shall not be liable for any damages caused by accidents, indirect, special or consequential damages, including but not limited to loss of profits, revenue or data, damages resulting from any breach of express or implied warranty or condition, or under any other legal theory, even if Xiaomi has been informed of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of special, indirect, or consequential damages, so the above limitation or exclusion may not apply to you.

7.XIAOMI CONTACTS

For customers, please visit the website: <https://www.mi.com/global/service/warranty/>

The contact person for the after-sale service may be any person in Xiaomi's authorized service network, Xiaomi's authorized distributors or the final vendor who sold the products to you. If in doubt please contact the relevant person as Xiaomi may identify.

- บริษัท: Beijing Smartmi Electronic Technology Co., Ltd.
(a Mi Ecosystem company)
ที่อยู่: Room 201-203, Unit 6, Building A, No. 66, Zhufang Road, Qinghe, Haidian District, Beijing
สำหรับข้อมูลเพิ่มเติม โปรดดูที่ www.mi.com
สำหรับคู่มือการใช้งานโปรดไปยังหน้าเว็บดู โปรดไปที่ www.mi.com/global/service/userguide
- Manufactured by: Beijing Smartmi Electronic Technology Co., Ltd.
(a Mi Ecosystem company)
Address: Room 201-203, Unit 6, Building A, No. 66, Zhufang Road, Qinghe, Haidian District, Beijing
For further information, please go to www.mi.com
For detailed e-manual, please go to www.mi.com/global/service/userguide