

No	Code	Name of Spare Parts	
1	30021100319	Hex Socket Head Screw M5×20	
2	30029900891	Exhaust Valve Cap	
3	30024500214	Exhaust Cover Spring	
4	30010300092	Rectangular Seal φ18×2.6	
5	30029900892	Cylinder Cover	
8	30029900847	Balance Valve	
9	30019900858	Flat Washer	
11	30019900859	Sleeve Retainer	
14	30009007479	Cylinder	
15	30019900483	Cushion	
17	30009007480	Shell	
18	30019900862	Flat Rubber Ring	
20	30019900863	Valve Base	
21	30029900898	Pneumatic Valve Lever	
23	30029900899	Pneumatic Valve Sleeve	
25	30024500224	Trigger Spring	
26	30029900900	Trigger Switch	
27	30021500092	Pin Φ3×18.5	
28	30010300101	Rectangular Seal φ5.0×2.0	
29	30029900895	Connector	
30	30021100098	Hex Socket Cap Screw M5×18	
31	30121310002	Hex Nut M5	
32	30009007504	Gun Cover	
33	30009007517	Baffle	
34	30009007505	Fixed Cartridge	
35	30009007497	Bracket	
38	30029900908	Positioning Hook	
39	30024500226	Torsion Spring_Positioning Hook	
40	30009007506	Adjusting Plate	
41	30021100021	Hex Socket Cap Screw M4×16	
43	30009007507	Top	
44	30009007508	Spring Retainer	
45	30009007509	Compression Spring_Top	
46	30009007510	Driver Guide	
47	30009007511	Movable Cartridge	
48	30009007512	Lock Buckle	
A	30009800071	Cylinder Cover Assembly A	#5-7
B	30009800072	Balance Valve Assembly B	#8-10
C	30005000081	Cylinder Cover Assembly C	#5+10
D	30005000131	Piston Assembly	#12-13
E	30009007481	F30 Cylinder Assembly	#10-15
F	30009008465	Shell Assembly (DongCheng)	
G	30005000084	Switch Assembly F	#20-24
H	30009800246	Trigger Switch Assembly	#25-28
I	30009007513	Magazine Assembly	
J	30009007503	Bracket Assembly	
L	30009800076	Spare Parts Kit L	

