

DCML20081

No	Code	Name of Spare Parts	Remark
1	30019901868	Lock Knob(Red)	
1	30019901960	Lock Knob(Black)	
2	30019901867	Chain Cover	
3	30019901869	Adjusting Knob(Red)	
4	30020700154	Gear Shaft	
5	30029902552	Straight Bevel Gear	
6	30029902551	Adjusting Pin	
7	30025200092	Flange	
8	30020700155	Adjusting Screw	
9	30021200016	Pan Head Tapping Screw ST2.9×9	
10	30021600041	Split Washer8	
11	30021600711	Washer (10×35×0.5) (Ep.)	
12	30029902578	Sprocket	
13	30021100090	Cross Recessed Small Pan Head Screw With Spring Washer M4×10	
14	30030100358	Switch (Red Trigger)	
15	30021600003	Circlip For Hole 32	
16	30020100241	Drive Spindle	
17	30021400061	Ball Bearing 6002ZZ	
18	30029902577	Planet Carrier	
19	30023300172	Gearbox	
20	30029902576	Inner Gear	
21	30020500452	Planetary Gear	
22	30025200091	Flange	
23	30021100670	Hex Socket Cap Screw M6×45	
24	30010000572	Oil Tube	
25	30009801108	Bubble	
26	30019901865	Oiler	
27	30010000136	Rubber Sleeve	
28	30010000565	Rubber Pad	
29	30019901866	Oiler Cap(Red)	
30	30029900817	Front Cover	
31	30021200089	Cross Recessed Pan Head Tapping Screw ST2.2×6	
32	30030200330	Controller Assembly	
33	30100300021	Stator	
34	30029900818	Rear Cover	
35	30021200192	Cross Recessed Pan Head Tapping Screw ST2.9×38	
36	30010000561	Rubber Pin	
37	30021200055	Pan Hd. Tapping Screw ST2.9×13	
38	30024500425	Torsion Spring	
39	30029902581	Bushing	
40	30019901870	Shield	
41	30021200193	Torx Pan Head Tapping Screw ST4.8×26.5	
42	30029902580	Chain-33E	
43	30429900013	Chain Plate(Dongcheng)	
44	30019901871	Blade Guard	
45	30050400004	Cable Tie	
46		Battery Pack	
47		Battery Charger	
T1	30415400259	Motor Housing (DongCheng)	
T2	30100200022	Armature Assembly	
T3	30009801109	Gearbox Assembly	Including: 15、16、17、18、19

