

DMQ02-65

No	Code	Name of Spare Parts	Remark
1	30009011393	Speed Controller(Without electronic control)	
2	30009011394	Push Button (Red)	
3	30009011395	Spring	
4	30009011396	Switch	
5	30009011397	Stop Pin	
6	30009011398	Eccentric Pin Of Blade-lifter	
7	30009011399	Motor Housing Assembly&Rubber Cover	ซ้าย-ขวา
7	30009011434	Motor Housing Assembly&Rubber Cover	ซ้าย-ขวา
8	30021200021	Pan Head Tapping Screw ST4X12	
9	30009011400	Strain Relief With Screw	
10	30009011401	Hex Cord Guard	
11	30030300305	Power Cord	
12	30009011403	ฟิลคอยล์	
13	30021400245	Ball Bearing 607-2RS	
14	30009011404	แปรงถ่าน	
15	30009011405	Carbon Brush Bracket&Brush Holder Cap	
16	30009011406	ท่อน	
17	30021400015	Ball Bearing 608ZZ	
18	30009011407	Proof-oil Felt Ring Of Bearing 608	
19	30021200060	Pan Head Tapping Screw ST4.2X30	
20	30009011408	Proof-oil Washer Of Bearing 608	
21	30021100395	Pan Head Tapping Screw ST4X24 (With Spring Washer)	
22	30009011409	Bracket	
23	30009011410	Needle Bearing <P6x<P9x13.5	
24	30009011411	Plastic Locating Plate	
25	30009011412	Blade-lifter Plate	
26	30009011413	Balance Block	
27	30009011414	Gear	
28	30009011415	Flat Washer <P6X<P12X0.5	
29	30009011416	Snap Ring <P6	
30	30009011417	5 X 5.5 X 10 Reciprocating Guide Wheel (Chamfering on Both Sides)	
31	30009011418	Rear Sliding Bearing of Reciprocating Lever	
32	30009011419	Reciprocating Lever Assembly	
33	30009011420	Reset Spring Of Blade Bar (B-shaped Spring)	
34	30009011421	Knob in Base Plate	
35	30009011422	Base Assembly	
36	30009011423	Angle Adjusting Plate	
37	30009011424	Cylindrical Pin <P4X25	
38	30009011425	Spring Of Blade-lifter Bracket	
39	30009011426	Blade-lifter Bracket Assembly	
40	30009011427	Base Fixing Plate	
41	30021100095	Hex Socket Cap Screw M5X12	
42	30009011428	Blade Orbit Selector Lever	
43	30009011429	Spring of Blade-lifter	
44	30009011430	<P4 Steel Ball	
46	30009011431	Cylindrical Pin <P3X7	
47	30179107011	Extended Ball-End Hex Wrench	
48	30009011432	Edge Guide	
49	30009011433	Dust Tube	

