

DSM10-100

No	Code	Name of Spare Parts	Remark
3	30023300027	Gear Housing	
4	30016000002	Air-Deflector Ring	
5	30021300018	Nut M7	
7	30021600064	Washer (8×17×0.3)	
8	30021400230	Ball Bearing 608-2RS-DC01	
9	30010400002	Square-Ring Seal (22×25.2×4)	
10	30024000012	Circlip for Hole	
11		หุ่น	220V
12	30016300014	Insulation Washer	
13	30021400245	Ball Bearing 607-2RS (LFK)	
14	30010500001	Rubber Bearing Sleeve (19×21.2×8.6)	
15	30021200020	Pan Head Tapping Screw ST4.2×25	
17	30021400040	Ball Bearing 688ZZ	
19	30021600003	Circlip For Hole 32	
20	30021400300	Ball Bearing 6201DDU-DC06	
21	30024000010	Dustproof Cover	
22	30020100031	Drive Spindle	
23	30023400019	Bearing Box	
24	30021100088	Pan Head Screw M4×14	
26	30005090011	Wheel Guard Assembly	
29	30016000008	Baffle Plate (Short)	
30		ฟิวส์	220V
31	30415400088	Motor Housing (DongCheng)	
33	30024500006	Belleville Spring	
34	30021100227	Pan Head Tapping Screw ST2.9×9	
35	30030600003	Carbon Brush	
36	30030700040	Brush Holder Assembly	
37		Speed controller 220V	
38	30016300001	Strain Relief	
39	30021200021	Pan Head Tapping Screw ST4×12	
40	30024500005	Return Spring (4.2×0.5×27)	
41	30016400005	Switch Knob (Black)	
42	30019900135	Switch Lever	
43	30030100054	Switch Assembly	110-220V
44	30030400011	Capacitor 0.33μF (2.8 Contact)	
45	30021200048	Pan Head Tapping Screw ST4.2×17	
46	30015500004	Rear Cover	
47	30010100035	Cord Guard (PVC)	
48		Power Cord	220V
861	30025100001	Wrench	
862	30015800031	Auxiliary Handle (M10)	
T1	30005090081	Gear And Pinion	Including 6 18
T2	30005090013	Flange Set	Including 27 28
T3	30005090014	Locking Assembly (Black)	Including : 1,2,16
T4	30005090080	Gear Housing Assembly (Black)	Including 1,2,3,16,17

