

KTW **Dong Cheng**
เกรียงไกรวัฒนากร **ดองเซ็ง ดีซัวร์**

No	Code	Name of Spare Parts	Remark
3	30020100210	Drive Spindle	
4	30029902250	Dust Cap	
5	30005090011	Wheel Guard Assembly	
6	30021100118	Cross Recessed Pan Head Tapping Screw M4×15 (With Spring Washer)	
7	30023400141	Gear Housing Cover	
8	30010300157	O Ring For Gear Housing	
9	30021400300	Ball Bearing 6201DDU-DC06	
10	30029902249	Circlip For Hole 34 (Non-Standard)	
12	30021400455	Needle Bearing HK0810 (INA)	
15	30021100225	Pan Head Tapping Screw ST4.2×20	
19	30009800934	Wool Filter Plug	
20	30021300141	Hex Nut M6	
22	30029902253	Washer (7×18.3×0.2)	
23	30021400011	Ball Bearing 608DD	
24	30023700105	608 Bearing Retainer	
25	30021100628	Cross Recessed Pan Head Screws M4×10	
26	30029902252	Washer (8.2×14.4×0.3)	
27		Armature	220-240V
28	30016300059	Insulation Washer	
29	30021400454	Ball Bearing 607DDW(NSK)	
30	30010000252	Rubber Bearing Sleeve	
31	30016000110	Baffle Plate	
32	30010000509	Rubber Pin (Φ4.5×11.5)	
33		Stator	220V
34	30415400164	Motor Housing (DongCheng)	
36	30021200140	Cross Recessed Pan Head Tapping Screw ST3.5×8	
37	30030600199	แปรงถ่าน (1 pcs Auto-Stop Type)	
38	30024500479	Flat Spiral Spring	
39	30030700076	Brush Holder Assembly	
40	30030100054	Switch Assembly	220V
41	30016300004	Strain Relief	
42	30021200036	Cross Recessed Pan Head Tapping Screw ST4.2×15	
43	30030400192	Capacitor	
44	30024500064	Return Spring (3.6×0.4×18)	
45	30016400073	Pull Rod	
46	30016400001	Switch Knob	
47	30015500041	Rear Cover	
48	30019901674	Detachable Air Window	
49	30010100029	Cord Guard (PVC)	
50		Power Cord	220V
51	30025100001	Wrench	
52	30015800031	Auxiliary Handle (M10)	
T1	30029902251	Locking Assembly	Including: 13 14 16 17
T2	30005090013	Flange Set	Including: 1 2
T3	30023300155	Gear Housing Assembly	Including: 12 18
T4	30023300154	Gear Housing Assembly	Including: 12-14, 16-19, 22-25
T5	30023400116	Gear Housing Cover Assembly	Including: 3, 4, 7-11, 21
T6	30020600128	Gear And Pinion	Including: 11 21

