

## 140FA 汽油机零部件明细表

\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \						l		T
房	名称	数量	房	名称	数量	房	名称	数量
1	法兰盘螺钉M5X15	7	32	磁电机定子	1		螺母M8	1
2	缸体护罩	1	33	螺栓组合件M4 <i>X1</i> 4	2		<b>垫圈</b> B	2
3	法兰盘螺钉M5X12	4	34	停车线	1	65	涨紧块组合	1
4	气门护罩	1		排气门	1	66	波形垫圈	2
5	油气分离块	1		进气门	1		螺钉轴	2
6	缸盖内罩组	1	37	平衡气管	1		销 B4X8	4
7	螺栓组合件M4X8	4	38	小卡环 (甲)	1	69	磁电机罩壳	1
8	密封圈	1	39	进气管密封圈	1	70	下半曲轴箱	1
9	气门护罩密封圈	1	40	螺钉 M5×55	2	71	法兰盘螺钉M5X32	4
10	气门弹簧座	2	41	进气管部件	1	72	油箱盖	1
11	气门弹簧	2	42	废气管	1	73	进气嘴	1
12	排气摇臂组	1	43	化油器垫	1	74	油箱内盖	1
13	进气摇臂组	1	44	化油器	1	75	端盖	1
14	摇臂销	2	45	空滤器内罩组	1	76	密封垫	1
15	排气摇臂拨块	1	46	法兰盘螺钉M5X22	6	77	橡胶减震块	4
16	进气摇臂拨块	1	47	滤芯	1	78	油箱	1
17	同步胶带	1	48	空滤器外罩	1	79	油管胶塞	1
18	凸轮齿轮	1	49	第一道活塞环	1	80	回油管	1
19	凸轮销轴	1	50	第二道活塞环	1	81	进油管	1
20	启动拨盘	1	51	刮片	2	82	燃油过滤器	1
21	起动器	1	52	村簧	1	83	活塞销挡环	2
22	进气管平垫	1	53	活塞	1			
23	小卡环	1	54	曲轴组件	1			
24	消音器下护板	1	55	活塞销	1			
25	螺母M5	4	56	小油封	1			
	双头螺栓	2	57	油标尺	1			
27	消音器	1		O形密封圈 14×2.65	1			
28	消音器挡坂	1	59	半圆键3X5X13	1			
29	火花塞	1	60	大油封	1			
30	缸体	1	61	簧片组	1			
31	高压线卡	1	62	磁电机转子	1			

## Appendix.list of 140FA Gasoline Engine Parts

SER. NO.	PART NAME	QTY.	SER. NO.	PART NAME	QTY.	SER. NO.	PART NAME	QTY
1	Screw M5×15	7	31	Fastener	1	61	Reed vavle	1
2	Cylinder cover	1	32	Ignition stator	1	62	Magneto rotor comp.	1
3	Screw M5×12	4	33	Screw M4X14	2	63	Nut M8	1
4	Cylinder valve cover	1	34	Stopping wire	1	64	Washer	2
5	Oil gas separator	1	35	Exhaust valve	1	65	Clutch	1
6	Inside cover	1	36	Inlet valve	1	66	Washer	2
7	Screw M4X8	4	37	Balancing pressure pipe	1	67	Screw pin	2
8	Rubber cushion	1	38	Holding-down clip	1	68	Pin B4X8	4
9	Rubber cushion	1	39	0-seal ring	1	69	Magneto cover	1
10	Valve spring seat	2	40	Screw M5×55	2	70	Crankcase	1
11	Valve spring	2	41	Admitting pipe	1	71	Screw M5×32	4
12	Exhaust valve rocker	1	42	Blast pipe	1	72	Fuel tank lid	1
13	Inlet valve rocker	1	43	Gasket	1	73	Air admission valve	1
14	Rocker pin	2	44	Carburetor	1	74	Inside cover	1
15	Exhaust rocker	1	45	Cleaner inside cover	1	75	Shell cover	1
16	Inlet rocker	1	46	Screw M5×22	6	76	Airproof gasket	1
17	Synchronous belt	1	47	Filter net	1	77	Rubber cushion	4
18	Cam wheel	1	48	Air filter cover	1	78	Fuel tank	1
19	Camshaft	1	49	NO1. piston ring	1	79	Plug	1
20	Start reel	1	50	NO2. piston ring	1	80	Fuel return pipe	1
21	Starter	1	51	Oil scraper ring	2	81	Fuel suction pipe	1
22	Admitting gasket	1	52	Liner ring	1	82	Filter	1
23	Holding-down clip	1	53	Piston	1	83	Ring	2
24	Muffler baffle-I	1	54	Crankshaft	1			
25	Nut M5	4	55	Piston pin	1			
26	Double-edged bolt	2	56	Oil seal	1			
27	Muffler	1	57	Oil scale	1			
28	Muffler baffle	1	58	0-seal ring 14×2.65	1			
29	Spark plug	1	59	Key 3X5X13	1			
30	Cylinder	1	60	Oil seal	1			