



1E40F-6C发动机分解图



BC411C割灌机分解图

Exploded view P271-PL411C Shaft



BC411C brush cutter explosive view parts list

page 1

NO	Part num	Description(Cn)	Description(En)	Quantity
1		1E40F-6C发动机	Engine	1
2	4010200101	28牧田款连接盘	connection plate	1
3	5231000201	内六角圆柱头螺钉M6×25	ScrewM6×25	1
4	5230901201	内六角圆柱头组合螺钉M6×25	ScrewM6×25	6
5	5879901101	长皮套\有开口	leather sheath	1
6	5259900101	碟形螺母	butterfly nut	1
7	5260100401	弹垫6	Spring washer Ø6	1
8	5260100101	平垫6	washer Ø6	1
9	5010102601	28铝管夹紧套	aluminum tube clamping sleeve	1
10	5130100201	铝管夹紧套隔离弹簧	spring	1
11	5239900101	外六角螺钉M6×45	ScrewM6×45	1
12	5310100501	1.45米28铝管厚1.5\铝本色	Aluminum pipe	1
13	5300400101	含油轴承\外径25.5	Oil-bearing	5
14	4990100601	割草机工具包\透明PE袋\17-19	Toolkit	1
15	5090100201	配比壶	Oiler	1
16	4990100201	普通单肩背带	Strap	1
17	5010102401	扎带	Ties	4
18	5230500101	内六角圆柱头组合螺钉M5×30	ScrewM5×30	3
19	5230500701	内六角圆柱头组合螺钉M5×14	ScrewM5×14	2
20	4010100101	28半圆头齿轮箱	Gearbox	1
21	5150105901	2T12英寸矩形黑色刀片	Rectangular blade	1
22	5250400201	方形螺母M6	Nut M6	2
23	5010158001	新款F型防护罩	Shield	1
24	5150102401	28防护罩固定铁片	Fixed plate	1
25	5231000601	内六角圆柱头螺钉M6×20	ScrewM6×20	2
26	4030300301	MKT款左把手\铝本色	Left hand	1
27	5190108201	28把手固定座总成	Handle Holder	1
28	5230500801	内六角圆柱头组合螺钉M5×25	ScrewM5×25	4
29	4030300101	MKT款右把手\铝本色	Right hand	1
30	5322100201	9齿传动轴\长度1500	Shaft	1
31	5260106601	平垫片28×33.5×2.5	washer 28×33.5×2.5	1
32	5280100101	轴卡\轴径27	hole	1
33	5250400101	六角螺母M6	Nut M6	3
34	3020102401	MKT三孔式连接铁片	Connection iron	1
35				
36				

[illegible]