BC.TGVE

VE GLOVE TESTER

Selling Propositions

- Truncated end with two grooves for holding the glove under test.
- Central piston at the bottom of the tester.
- Flexible valve at the bottom of the bowl on the upper part.
- 2 rubber rings to hold the glove during inflation.
- Purpose of the tester is to ensure that glove is absolutely air tight.For your safety, this test should be done before and after using the gloves.

Standard Equipment

Warranty specifications

- legal

Specifications	
Weight	500.0 g
Height	13.5 cm
Width	12.5 cm
Length	13.5 cm