JUMO GmbH & Co. KG
Delivery address: Mackenrodtstraße 14,
36039 Fulda, Germany
Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
e-mail: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.
JUMO House
Temple Bank, Riverway
Harlow, Essex CM 20 2TT, UK
Phone: +44 1279 635533
Fax: +44 1279 635262
e-mail: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.
8 Technology Boulevard
Canastota, NY 13032, USA
Phone: 315-697-JUMO
1-800-554-JUMO
Fax: 315-697-5867
e-mail: info@jumo.us
Internet: www.jumo.us

Software
for Indicators, Recorders and Temperature Transmitters

available for download at: http://www2.jumo.de/index_www2.html

Device designation		Device software version
di 308	Data Sheet 701550	217.xx.xx
di 32 / di 08	Data Sheet 701530	149.xx.xx
di eco	Data Sheet 701540	168.xx.xx
LOGOLINE 500d	Data Sheet 706021	078.xx.xx
LOGOPRINT 500	Data Sheet 706030	105.xx.xx
LOGOSCREEN 500 cf	Data Sheet 706510	208.01.xx
LOGOSCREEN es	Data Sheet 706560	172.xx.xx
LOGOSCREEN cf	Data Sheet 706570	172.xx.xx
LOGOSCREEN nt	Data Sheet 706581	187.xx.xx
dTRANS T01	Data Sheet 707010	114/153.xx.xx
dTRANS T02	Data Sheet 707020	135/151.xx.xx
dTRANS T03	Data Sheet 707030	194.xx.xx
dTRANS T04	Data Sheet 707040	199.xx.xx

													Software programs[1] (multilingual)		**Sales No.**
						x							PC software package, consisting of: Setup-Program, PC Evaluation software (PCA3000), PCA Communications software (PCC), PC Security Manager (PCS) and PC Audit Trail Manager (PCAT)		70/00417278
						x							IQ / OQ documentation (German / English)		70/00436829
						x							IQ / OQ documentation (French / English)		70/00441797
					x		x	x					PC Evaluation software (PCA3000)	177.xx.xx	70/00431882
					x	x	x	x					Enable automatic printout (version 177.03.xx/3.00 or above)		70/00505548
					x		x	x					PCA Communications software (PCC)	178.xx.xx	70/00431879
				x									Setup program		70/00361535
			x										Setup program		70/00355073
										x			Setup program		70/00378730
											x		Setup program		70/00397093
									x				Setup program		70/00378733
								x					Setup program		70/00432408
	x												Setup program		70/00438980
		x											Setup program		70/00419998
												x	Setup program		70/00448774
					x								Setup program		70/00467262
								x					Setup program including cable-USB		70/00468991
x													Setup program		70/00493223

[1] Delivery time for software: about 3 working days

JUMO GmbH & Co. KG
Delivery address: Mackenrodtstraße 14,
36039 Fulda, Germany
Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
e-mail: mail@jumo.net
Internet: www.jumo.net





JUMO Instrument Co. Ltd.
JUMO House
Temple Bank, Riverway
Harlow, Essex CM 20 2TT, UK
Phone: +44 1279 635533
Fax: +44 1279 635262
e-mail: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.
8 Technology Boulevard
Canastota, NY 13032, USA
Phone: 315-697-JUMO
1-800-554-JUMO
Fax: 315-697-5867
e-mail: info@jumo.us
Internet: www.jumo.us

Accessories
for Indicators, Recorders and Temperature Transmitters

Device designation	
di 308	Data Sheet 701550
di 32 / di 08	Data Sheet 701530
di eco	Data Sheet 701540
LOGOLINE 500d	Data Sheet 706021
LOGOPRINT 500	Data Sheet 706030
LOGOSCREEN 500 cf	Data Sheet 706510
LOGOSCREEN es	Data Sheet 706560
LOGOSCREEN cf	Data Sheet 706570
LOGOSCREEN nt	Data sheet 706581
dTRANS T01	Data Sheet 707010
dTRANS T02	Data Sheet 707020
dTRANS T03	Data Sheet 707030
dTRANS T04	Data Sheet 707040

													Accessories	**Sales No.**	
	x	x	x	x	x	x	x		x	x		x	Converter cable USB-serial	70/00408077	
					x			x					Enable math/logic module	70/00393217	
				x									4-way relay module for open-collector outputs	70/00404537	
				x	x								ER8 relay module, 110 — 240 V AC[2]	70/00405292	
				x	x								ER8 relay module, 20 — 53 V AC[2]	70/00405297	
				x	x								PC interface with TTL/RS232 converter	70/00301315	Figure 1
x	x	x	x	x	x	x	x		x	x		x	PC interface with USB/TTL converter, adapter (socket) and adapter (pins)	70/00456352	Figure 2
x					x	x	x		x	x		x	PC interface with TTL/RS232 converter and adapter (socket)	70/00350260	Figure 3
	x	x											PC interface with TTL/RS232 converter and adapter (pins)	70/00400821	Figure 4
											x		PC interface with USB/SPI converter and adapter (socket)	70/00553388	
					x	x	x	x					RS232 interface cable (9/9-pole)	70/00367735	
					x	x	x	x					RS232 interface cable (9/25-pole)	70/00367736	
					x	x	x	x					CF-card reader (USB2.0)	70/00423136	
					x	x	x	x					CF-card adapter, type II	70/00424310	
					x	x	x	x					CompactFlash 256 MB	70/00463462	
					x	x	x	x					CompactFlash 1 GB	70/00548080	
								x					USB flash drive 1 GB	70/00505592	
					x	x	x	x					Modem cable 5m (2x 9-pole pin)	70/00427093	
					x	x	x	x					Modem cable 5m (25/9-pole pin)	70/00431871	
									x		x		Fixing bracket, for mounting the B head transmitter on DIN rail	70/00352463	
								x					Barcode-reader with RS232 interface	70/00407798	
								x					Relay 3 A, 230 V AC for connecting to binary output	70/00515872	
					x	x	x	x					Analog DIN rail modem, configured, with accessories	70/00416612	
					x	x	x	x					ISDN DIN rail modem, configured, with accessories	70/00416611	
					x	x	x	x					GSM modem, configured, with accessories	70/00440255	
					x	x	x	x					TIXI GSM (wireless modem with Alert-Function)	70/00487003	
					x	x	x	x					Software TICOLA	70/00487002	

Figure 1	Figure 2	Figure 3	Figure 4
	 with 2 connecting cables		

[2] extra code is necessary