AC Current Transducer AP-B10

I_{PN} = 10 ... 400 A

Split-core transducer for the electronic measurement AC sinusoidal waveform currents, with galvanic separation between the primary circuit and the secondary circuit. Switch selectable measuring ranges and rms 0-5 V and 0-10 V switch selectable voltage output.



Elecrical data

Primary nominal current I_{PN} (At.rms)	Output voltage (Analog) V_{OUT} (V DC)	Types	RoHS since date code
10, 25, 50	0-5 or 0-10	**AP 50 B10**	46320
50, 75, 100	0-5 or 0-10	**AP 100 B10**	46333
100, 150, 200	0-5 or 0-10	**AP 200 B10**	47282
200, 300, 400	0-5 or 0-10	**AP 400 B10**	48245

U_C	Supply voltage	+24 ±5 %	V DC
R_L	Load resistance	≥ 10	kΩ
V_{SL}	Output voltage limitation (0-10 V)	14	V
V_{SL}	Output voltage limitation (0-5 V)	7	V
I_C	Maximum current consumption	< 30	mA
$\hat{I}_P$	Overload capability	no limitation	

Accuracy - Dynamic performance data

X	Accuracy @ I_{PN}, T_A = 25 °C (excluding offset)	< ±1	% of I_{PN}
ε_L	Linearity error (0 … ± I_{PN})	< ±0.5	% of I_{PN}
V_{OE}	Electrical offset voltage @ T_A = 25 °C	< ±0.5	% of I_{PN}
TCV_{OE}	Temperature coefficient of V_{OE}	±1	mV/K
TCV_{OUT}	Temperature coefficient of V_{OUT} (% of reading)	±0.1	%/K
t_r	Step response time to 90 % of I_{PN}	< 150	ms
BW	Frequency bandwidth (±1 %)	30 … 2000	Hz

General data

T_A	Ambient operating temperature	−20 … +60	°C
T_S	Ambient storage temperature	−20 … +85	°C
m	Mass	90	g
IPxx	Protection degree	IP 20	

Features

- Rms output (average)
- Split-core type
- 0-5 V DC and 0-10 V DC switch selectable voltage output
- DIN rail or Panel mounting
- Switch selectable measuring ranges
- Insulating plastic case recognized according to UL 94-V0.

Advantages

- Large aperture for cable up to ⌀ 18 mm
- High insulation between primary and secondary circuits
- Eliminates insertion loss
- Easy installation.

Applications

- ***Automation systems***
  Analog current reading for remote monitoring (e.g. motor) and sotware alarms.
- ***Panel meters***
  Simple connection to power consumption displays.

Application domains

- Energies and Automation.

LEM reserves the right to carry out modifications on its transducers, in order to improve them, without prior notice

Current Transducer AP-B10

Insulation coordination

U_b	Rated insulation rms voltage [1], with IEC 61010-1 standards and following conditions: - Reinforced insulation - Over voltage category CAT III - Pollution degree PD2 - Heterogeneous field	300	V
U_d	Rms voltage for AC insulation test [2], 50 Hz, 1 min	5	kV
U_e	Partial discharge extinction rms voltage @ 10 pC	1.5	kV
$\hat{U}_W$	Impulse withstand voltage 1.2/50 µs	6.1	kV
d_{CP}	Creepage distance	5.5	mm
d_{Cl}	Clearance	5.5	mm
CTI	Comparative tracking index (Group I)	600	

Notes: [1] If insulated cable is used for the primary circuit, the voltage category could be improved according to the insulation coordination given by the cable manufacturer.
For example:

Cable insulation (primary)	Category
HAR 05	600 V CAT III
HAR 07	1000 V CAT III

[2] Between primary (completely filling the primary aperture) and secondary.

LEM reserves the right to carry out modifications on its transducers, in order to improve them, without prior notice

Safety and warning notes

In order to guarantee safe operation of the transducer and to be able to make proper use of all features and functions, please read these instructions thoroughly! Safe operation can only be guaranteed if the transducer is used for the purpose it has been designed for and within the limits of the technical specifications.
Ensure you get up-to-date technical information that can be found in the latest associated datasheet under www.lem.com.



Caution! Risk of danger

Ignoring the warnings can lead to serious injury and/or cause damage!
The electric measuring transducer may only be installed and put into operation by qualified personnel that have received an appropriate training.
The corresponding national regulations shall be observed during installation and operation of the transducer and any electrical conductor.
The transducer shall be used in electric/electronic equipment with respect to applicable standards and safety requirements and in accordance with all the related systems and components manufacturer' operating instructions.




Caution, Risk of electrical shock

When operating the transducer, certain parts of the module may carry hazardous live voltage (eg. primary conductor, power supply).
The user shall ensure to take all measures necessary to protect against electical shock. The transducer is a build-in device containing conducting parts that shall not be accessible after installation.
A protective enclosure or additional insulation barrier may be necessary.
The transducer shall not be put into operation if the jaw opening is open (split core version) or the installation is not completed.
Installation and maintenance shall be done with the main power supply disconnected except if there are no hazardous live parts in or in close proximity to the system and if the applicable national regulations are fully observed.


Safe and trouble-free operation of this transducer can only be guaranteed if transport, storage and installation are carried out correctly and operation and maintenance are carried out with care.


LEM reserves the right to carry out modifications on its transducers, in order to improve them, without prior notice

Dimensions AP(R)-B10 (in mm)



0-5, 10V Selectable





Connections

- Wires up to ⌀ 2 mm
- Female connector provided (spring terminal blocks)
- User-friendly spring-cage connection for no-tool direct conductor connection

Mechanical characteristics

- General tolerance ±1 mm
- Primary aperture ⌀ 18.5 mm
- Panel mounting 2 holes ⌀ 4 mm
- Distance between holes 40 mm

  For panel mounting, replace M4 screws by new one (not supplied) with appropriate length to panel's thickness.

LEM reserves the right to carry out modifications on its transducers, in order to improve them, without prior notice