# Slide-hammer valve lifter



## Description:

- For removing valve springs.
- The slide hammer is used to free split collets.
- Diameter: 34 mm.

| | Length L [mm] | Height H [mm] | Length [mm] | Weight [Kg] |
|---|---|---|---|---|
| U.43LA | 200.0 | 36.0 | 390.0 | 1.4 |

© FACOM 2020