


| Description | Mounting bracket for M8 | Mounting bracket for M12 | Mounting bracket for M16 | Mounting bracket for M18 |
|---|---|---|---|---|
| Ordering code | BES 08-HW-1 | BES 12-HW-1 | BES 16-HW-1 | BES 18-HW-1 |




| Description | Mounting bracket for M24 | Mounting bracket for M30 | Mounting bracket for M36 | |
|---|---|---|---|---|
| Ordering code | BES 24-HW-1 | BES 30-HW-1 | BES 36-HW-1 | |



These aluminum mounting brackets provide a way of easily and quickly attaching sensors to the machine.

For tubular sensors we recommend the additional use of clamps (see pages **6.**20 and **6.**21).

