

Recycle bin

Product code: Bin01

Overview

The Skipper sack holder bin is designed for multi-purpose waste and recycling use. With a wealth of versatile attachments it can be used indoors and outdoors with the Skipper Post & Base system via a collar, the cord strap clip, the Skipper suction pad bracket and, for permanent fixing, the Skipper wall clip.

Product Specifications

Width: 338mm	**Height: 194mm**
Depth: 376mm	**Weight: 1.1kg**

Key selling points

- Versatile design allows the recycle bin to attach to almost any surface
- Available in a range of lid colours (orange, green, red, blue, silver)

Key features

- Connects to the post & base collar, cord strap clip, wall clip and suction pad bracket
- Holds up to 15KG
- Supplied with stickers to designate general waste or recycling use

2 recycle bins can be attached to the Skipper post and base system via the post & base collar



Product FAQs

Q. What types of bag should be used with the recycle bin?

A. You can use any standard sized bag (simply lift the outer and inner lid and tuck the bag into the groove.

Q. What should I use the bin for?

A. The bin is designed to be used in a range of sectors including cleaning & hygiene, utilities, facilities management and construction (up to 15KG weight)