3AUA0000088311

ACS-AP-I; ACS-AP-I Panel packed kit

General Information

Product ID	3AUA0000088311
ABB Type Designation	ACS-AP-I
EAN	6438177306757
Catalog Description	ACS-AP-I; ACS-AP-I Panel packed kit

Ordering

Customs Tariff Number	85049099
EAN	6438177306757
Invoice Description	ACS-AP-I Panel packed kit
Minimum Order Quantity	1 piece
Selling Unit of Measure	piece

Dimensions

Product Net Height	32 mm
Product Net Weight	0.13 kg
Product Net Width	80 mm

Additional Information

Country of Origin	China (CN) United States (US) Thailand (TH)
Product Main Type	ACS-AP-I
Product Name	Control Panel
WEEE Category	Product Not in WEEE Scope

Classifications

UNSPSC	39120000

Where Used (as a spare part for "Products")

Identifier	Description	Quantity	Unit Of Measure

ACS880-01-13A4-3	No Description Available	1	piece
ACS880-01-17A5-3	No Description Available	1	piece
ACS880-01-25A1-3	No Description Available	1	piece
ACS880-01-428A-3	No Description Available	1	piece
ACS880-1607-0600A-3	No Description Available	1	piece
ACS880-1607-0900A-3	No Description Available	1	piece
ACS880-1607-1200A-3	No Description Available	1	piece
ACS880-1607-1800A-3	No Description Available	1	piece
ACS880-1607-2700A-3	No Description Available	1	piece
ACS880-1607-3600A-3	No Description Available	1	piece
ACS880-1607-4500A-3	No Description Available	1	piece
ACS880-1607-0600A-5	No Description Available	1	piece
ACS880-1607-0900A-5	No Description Available	1	piece
ACS880-1607-1200A-5	No Description Available	1	piece
ACS880-1607-1800A-5	No Description Available	1	piece
ACS880-1607-2700A-5	No Description Available	1	piece
ACS880-1607-3600A-5	No Description Available	1	piece
ACS880-1607-4500A-5	No Description Available	1	piece
ACS880-1607-0400A-7	No Description Available	1	piece
ACS880-1607-0600A-7	No Description Available	1	piece
ACS880-1607-0800A-7	No Description Available	1	piece
ACS880-1607-1200A-7	No Description Available	1	piece
ACS880-1607-1800A-7	No Description Available	1	piece
ACS880-1607-2400A-7	No Description Available	1	piece
ACS880-1607-3000A-7	No Description Available	1	piece
ACS880-907-0600A-3	No Description Available	1	piece
ACS880-907-0900A-3	No Description Available	1	piece
ACS880-907-1180A-3	No Description Available	1	piece
ACS880-907-1770A-3	No Description Available	1	piece
ACS880-907-2310A-3	No Description Available	1	piece
ACS880-907-3460A-3	No Description Available	1	piece
ACS880-907-0600A-5	No Description Available	1	piece
ACS880-907-0900A-5	No Description Available	1	piece
ACS880-907-1180A-5	No Description Available	1	piece
ACS880-907-1770A-5	No Description Available	1	piece
ACS880-907-2310A-5	No Description Available	1	piece
ACS880-907-3460A-5	No Description Available	1	piece
ACS880-907-0600A-7	No Description Available	1	piece
ACS880-907-0900A-7	No Description Available	1	piece
ACS880-907-1180A-7	No Description Available	1	piece
ACS880-907-1770A-7	No Description Available	1	piece

ACS880-907-2310A-7	No Description Available	1	piece
ACS880-907-3460A-7	No Description Available	1	piece
ACS880-607-0500-3	No Description Available	1	piece
ACS880-607-0750-3	No Description Available	1	piece
ACS880-607-1000-3	No Description Available	1	piece
ACS880-607-1510-3	No Description Available	1	piece
ACS880-607-2260-3	No Description Available	1	piece
ACS880-607-3010-3	No Description Available	1	piece
ACS880-607-3770-3	No Description Available	1	piece
ACS880-607-0630-5	No Description Available	1	piece
ACS880-607-0940-5	No Description Available	1	piece
ACS880-607-1260-5	No Description Available	1	piece
ACS880-607-1880-5	No Description Available	1	piece
ACS880-607-2830-5	No Description Available	1	piece
ACS880-607-3770-5	No Description Available	1	piece
ACS880-607-4710-5	No Description Available	1	piece
ACS880-607-0870-7	No Description Available	1	piece
ACS880-607-1300-7	No Description Available	1	piece
ACS880-607-1730-7	No Description Available	1	piece
ACS880-607-2600-7	No Description Available	1	piece
ACS880-607-3900-7	No Description Available	1	piece
ACS880-607-5200-7	No Description Available	1	piece
ACS880-607-6500-7	No Description Available	1	piece
ACS880-307-0080A-3	No Description Available	1	piece
ACS880-307-0170A-3	No Description Available	1	piece
ACS880-307-0330A-3	No Description Available	1	piece
ACS880-307-0490A-3	No Description Available	1	piece
ACS880-307-0650A-3	No Description Available	1	piece
ACS880-307-0980A-3	No Description Available	1	piece
ACS880-307-0080A-5	No Description Available	1	piece
ACS880-307-0170A-5	No Description Available	1	piece
ACS880-307-0330A-5	No Description Available	1	piece
ACS880-307-0490A-5	No Description Available	1	piece
ACS880-307-0650A-5	No Description Available	1	piece
ACS880-307-0980A-5	No Description Available	1	piece
ACS880-307-0910A-3	No Description Available	1	piece
ACS880-307-1210A-3	No Description Available	1	piece
ACS880-307-1820A-3	No Description Available	1	piece
ACS880-307-2430A-3	No Description Available	1	piece
ACS880-307-2730A-3	No Description Available	1	piece
ACS880-307-3640A-3	No Description Available	1	piece

ACS880-307-4560A-3	No Description Available	1	piece
ACS880-307-5470A-3	No Description Available	1	piece
ACS880-307-0910A-5	No Description Available	1	piece
ACS880-307-1210A-5	No Description Available	1	piece
ACS880-307-1820A-5	No Description Available	1	piece
ACS880-307-2430A-5	No Description Available	1	piece
ACS880-307-2730A-5	No Description Available	1	piece
ACS880-307-3640A-5	No Description Available	1	piece
ACS880-307-4560A-5	No Description Available	1	piece
ACS880-307-5470A-5	No Description Available	1	piece
ACS880-307-0570A-7	No Description Available	1	piece
ACS880-307-0760A-7	No Description Available	1	piece
ACS880-307-0820A-7	No Description Available	1	piece
ACS880-307-1060A-7	No Description Available	1	piece
ACS880-307-1520A-7	No Description Available	1	piece
ACS880-307-2130A-7	No Description Available	1	piece
ACS880-307-2280A-7	No Description Available	1	piece
ACS880-307-3040A-7	No Description Available	1	piece
ACS880-307-3800A-7	No Description Available	1	piece
ACS880-307-4560A-7	No Description Available	1	piece
ACS880-207-0420A-3	No Description Available	1	piece
ACS880-207-0580A-3	No Description Available	1	piece
ACS880-207-0810A-3	No Description Available	1	piece
ACS880-207-0400A-5	No Description Available	1	piece
ACS880-207-0530A-5	No Description Available	1	piece
ACS880-207-0730A-5	No Description Available	1	piece
ACS880-207-2350A-3	No Description Available	1	piece
ACS880-207-2120A-5	No Description Available	1	piece
ACS880-207-0310A-7	No Description Available	1	piece
ACS880-207-0370A-7	No Description Available	1	piece
ACS880-207-0540A-7	No Description Available	1	piece
ACS880-207-1570A-7	No Description Available	1	piece
ACS880-207-1130A-3	No Description Available	1	piece
ACS880-207-1330A-3	No Description Available	1	piece
ACS880-207-1580A-3	No Description Available	1	piece
ACS880-207-3110A-3	No Description Available	1	piece
ACS880-207-4620A-3	No Description Available	1	piece
ACS880-207-1040A-5	No Description Available	1	piece
ACS880-207-1420A-5	No Description Available	1	piece
ACS880-207-2800A-5	No Description Available	1	piece
ACS880-207-4150A-5	No Description Available	1	piece

ACS880-207-0720A-7	No Description Available	1	piece
ACS880-207-1050A-7	No Description Available	1	piece
ACS880-207-2070A-7	No Description Available	1	piece
ACS880-207-3080A-7	No Description Available	1	piece
ACS880-207-4100A-7	No Description Available	1	piece
ACS880-207-5130A-7	No Description Available	1	piece
ACS880-107-0470A-3	No Description Available	1	piece
ACS880-107-0640A-3	No Description Available	1	piece
ACS880-107-0760A-3	No Description Available	1	piece
ACS880-107-0900A-3	No Description Available	1	piece
ACS880-107-1250A-3	No Description Available	1	piece
ACS880-107-1480A-3	No Description Available	1	piece
ACS880-107-1760A-3	No Description Available	1	piece
ACS880-107-2210A-3	No Description Available	1	piece
ACS880-107-2610A-3	No Description Available	1	piece
ACS880-107-3450A-3	No Description Available	1	piece
ACS880-107-4290A-3	No Description Available	1	piece
ACS880-107-5130A-3	No Description Available	1	piece
ACS880-107-0440A-5	No Description Available	1	piece
ACS880-107-0590A-5	No Description Available	1	piece
ACS880-107-0740A-5	No Description Available	1	piece
ACS880-107-0810A-5	No Description Available	1	piece
ACS880-107-1150A-5	No Description Available	1	piece
ACS880-107-1450A-5	No Description Available	1	piece
ACS880-107-1580A-5	No Description Available	1	piece
ACS880-107-2150A-5	No Description Available	1	piece
ACS880-107-2350A-5	No Description Available	1	piece
ACS880-107-3110A-5	No Description Available	1	piece
ACS880-107-3860A-5	No Description Available	1	piece
ACS880-107-4610A-5	No Description Available	1	piece
ACS880-107-0340A-7	No Description Available	1	piece
ACS880-107-0410A-7	No Description Available	1	piece
ACS880-107-0530A-7	No Description Available	1	piece
ACS880-107-0600A-7	No Description Available	1	piece
ACS880-107-0800A-7	No Description Available	1	piece
ACS880-107-1030A-7	No Description Available	1	piece
ACS880-107-1170A-7	No Description Available	1	piece
ACS880-107-1540A-7	No Description Available	1	piece
ACS880-107-1740A-7	No Description Available	1	piece
ACS880-107-2300A-7	No Description Available	1	piece
ACS880-107-2860A-7	No Description Available	1	piece

ACS880-107-3420A-7	No Description Available	1	piece
ACS880-107-3990A-7	No Description Available	1	piece
ACS880-107-4560A-7	No Description Available	1	piece
ACS880-107-5130A-7	No Description Available	1	piece
ACS880-107-5700A-7	No Description Available	1	piece
ACS880-107-0062A-7	No Description Available	1	piece
ACS880-107-0082A-7	No Description Available	1	piece
ACS880-107-0100A-7	No Description Available	1	piece
ACS880-107-0130A-7	No Description Available	1	piece
ACS880-107-0140A-7	No Description Available	1	piece
ACS880-107-0190A-7	No Description Available	1	piece
ACS880-107-0220A-7	No Description Available	1	piece
ACS880-107-0270A-7	No Description Available	1	piece
ACS880-107-0011A-3	No Description Available	1	piece
ACS880-107-0014A-3	No Description Available	1	piece
ACS880-107-0018A-3	No Description Available	1	piece
ACS880-107-0025A-3	No Description Available	1	piece
ACS880-107-0035A-3	No Description Available	1	piece
ACS880-107-0044A-3	No Description Available	1	piece
ACS880-107-004A8-3	No Description Available	1	piece
ACS880-107-0050A-3	No Description Available	1	piece
ACS880-107-0061A-3	No Description Available	1	piece
ACS880-107-006A0-3	No Description Available	1	piece
ACS880-107-0078A-3	No Description Available	1	piece
ACS880-107-008A0-3	No Description Available	1	piece
ACS880-107-0094A-3	No Description Available	1	piece
ACS880-107-0100A-3	No Description Available	1	piece
ACS880-107-0140A-3	No Description Available	1	piece
ACS880-107-0170A-3	No Description Available	1	piece
ACS880-107-0210A-3	No Description Available	1	piece
ACS880-107-0250A-3	No Description Available	1	piece
ACS880-107-0300A-3	No Description Available	1	piece
ACS880-107-0350A-3	No Description Available	1	piece
ACS880-107-0011A-5	No Description Available	1	piece
ACS880-107-0014A-5	No Description Available	1	piece
ACS880-107-0018A-5	No Description Available	1	piece
ACS880-107-0025A-5	No Description Available	1	piece
ACS880-107-0030A-5	No Description Available	1	piece
ACS880-107-0035A-5	No Description Available	1	piece
ACS880-107-003A6-5	No Description Available	1	piece
ACS880-107-004A8-5	No Description Available	1	piece

ACS880-107-0050A-5	No Description Available	1	piece
ACS880-107-0061A-5	No Description Available	1	piece
ACS880-107-006A0-5	No Description Available	1	piece
ACS880-107-0078A-5	No Description Available	1	piece
ACS880-107-008A0-5	No Description Available	1	piece
ACS880-107-0094A-5	No Description Available	1	piece
ACS880-107-0110A-5	No Description Available	1	piece
ACS880-107-0140A-5	No Description Available	1	piece
ACS880-107-0170A-5	No Description Available	1	piece
ACS880-107-0200A-5	No Description Available	1	piece
ACS880-107-0240A-5	No Description Available	1	piece
ACS880-107-0300A-5	No Description Available	1	piece
ACS880-107-0340A-5	No Description Available	1	piece
ACS880-107-0018A-7	No Description Available	1	piece
ACS880-107-0022A-7	No Description Available	1	piece
ACS880-107-0027A-7	No Description Available	1	piece
ACS880-107-0035A-7	No Description Available	1	piece
ACS880-107-0042A-7	No Description Available	1	piece
ACS880-107-0052A-7	No Description Available	1	piece
ACS880-107-007A3-7	No Description Available	1	piece
ACS880-107-009A8-7	No Description Available	1	piece
ACS880-107-014A2-7	No Description Available	1	piece
ACS880-01-442A-3	No Description Available	1	piece
ACS880-01-441A-5	No Description Available	1	piece
PVS980-58-1818kVA-I	No Description Available	1	piece
PVS980-58-1909kVA-I	No Description Available	1	piece
PVS980-58-2000kVA-K	No Description Available	1	piece
ACS880-01-364A-3	No Description Available	1	piece
ACS880-01-303A-5	No Description Available	1	piece
ACS880-01-362A-5	No Description Available	1	piece
ACS880-01-415A-5	No Description Available	1	piece
ACS880-04F-504A-3	No Description Available	1	piece
ACS880-04F-584A-3	No Description Available	1	piece
ACS880-04F-649A-3	No Description Available	1	piece
ACS880-04F-725A-3	No Description Available	1	piece
ACS880-04F-820A-3	No Description Available	1	piece
ACS880-04F-880A-3	No Description Available	1	piece
ACS880-04F-459A-5	No Description Available	1	piece
ACS880-04F-502A-5	No Description Available	1	piece
ACS880-04F-582A-5	No Description Available	1	piece
ACS880-04F-634A-5	No Description Available	1	piece

ACS880-04F-715A-5	No Description Available	1	piece
ACS880-04F-820A-5	No Description Available	1	piece
ACS880-04F-880A-5	No Description Available	1	piece
ACS880-04F-329A-7	No Description Available	1	piece
ACS880-04F-369A-7	No Description Available	1	piece
ACS880-04F-429A-7	No Description Available	1	piece
ACS880-04F-470A-7	No Description Available	1	piece
ACS880-04F-522A-7	No Description Available	1	piece
ACS880-04F-590A-7	No Description Available	1	piece
ACS880-04F-650A-7	No Description Available	1	piece
ACS880-04F-721A-7	No Description Available	1	piece
ACS880-M04-04-03A0-2	No Description Available	1	piece
ACS880-M04-04-03A6-2	No Description Available	1	piece
ACS880-M04-04-04A8-2	No Description Available	1	piece
ACS880-M04-04-06A0-2	No Description Available	1	piece
ACS880-M04-04-08A0-2	No Description Available	1	piece
ACS880-M04-04-010A-2	No Description Available	1	piece
ACS880-M04-04-014A-2	No Description Available	1	piece
ACS880-M04-04-018A-2	No Description Available	1	piece
ACS880-M04-04-025A-2	No Description Available	1	piece
ACS880-M04-04-030A-2	No Description Available	1	piece
ACS880-M04-04-035A-2	No Description Available	1	piece
ACS880-M04-04-044A-2	No Description Available	1	piece
ACS880-M04-04-050A-2	No Description Available	1	piece
ACS880-M04-04-061A-2	No Description Available	1	piece
ACS880-M04-04-078A-2	No Description Available	1	piece
ACS880-M04-04-094A-2	No Description Available	1	piece
ACS880-M04-04-03A0-5	No Description Available	1	piece
ACS880-M04-04-03A6-5	No Description Available	1	piece
ACS880-M04-04-04A8-5	No Description Available	1	piece
ACS880-M04-04-06A0-5	No Description Available	1	piece
ACS880-M04-04-08A0-5	No Description Available	1	piece
ACS880-M04-04-010A-5	No Description Available	1	piece
ACS880-M04-04-014A-5	No Description Available	1	piece
ACS880-M04-04-018A-5	No Description Available	1	piece
ACS880-M04-04-025A-5	No Description Available	1	piece
ACS880-M04-04-030A-5	No Description Available	1	piece
ACS880-M04-04-035A-5	No Description Available	1	piece
ACS880-M04-04-044A-5	No Description Available	1	piece
ACS880-M04-04-050A-5	No Description Available	1	piece
ACS880-M04-04-061A-5	No Description Available	1	piece

ACS880-M04-04-078A-5	No Description Available	1	piece
ACS880-M04-04-094A-5	No Description Available	1	piece
PVS980-58-1909kVA-J	No Description Available	1	piece
PVS980-58-2091kVA-L	No Description Available	1	piece

—

Where Used (as part of "kit")

Identifier	Description	Type
3AXD50000192182	3AXD50000192182 Kit	Kit

—

Product specific part data

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-01-13A4-3	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-17A5-3	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-25A1-3	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-428A-3	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-1607-0600A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-0900A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-1200A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-1800A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-2700A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-3600A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-4500A-3	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-0600A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-0900A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-1200A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-1800A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-2700A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-3600A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-4500A-5	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-0400A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-0600A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-0800A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-1607-1200A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-1800A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-2400A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-1607-3000A-7	ACS880-1607 - DC-DC converter (DDC)	Control Panels, Displays and Accessories		
ACS880-907-0600A-3	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-0900A-3	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-1180A-3	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-1770A-3	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-2310A-3	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-3460A-3	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-0600A-5	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-0900A-5	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-1180A-5	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-1770A-5	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-2310A-5	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-3460A-5	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-0600A-7	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-0900A-7	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-1180A-7	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-1770A-7	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-2310A-7	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-907-3460A-7	ACS880-907 - Regenerative rectifier unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-607-0500-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-0750-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-1000-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-1510-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-2260-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-3010-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-3770-3	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-607-0630-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-0940-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-1260-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-1880-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-2830-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-3770-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-4710-5	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-0870-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-1300-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-1730-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-2600-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-3900-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-5200-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-607-6500-7	ACS880-607 - Brake unit	Control Panels, Displays and Accessories	Dynamic Braking Unit (DBU)	
ACS880-307-0080A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Diode Supply Unit (DSU) Auxiliary Control Unit (ACU)	
ACS880-307-0170A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0330A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Diode Supply Unit (DSU) Auxiliary Control Unit (ACU)	
ACS880-307-0490A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0650A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0980A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0080A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0170A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Diode Supply Unit (DSU) Auxiliary Control Unit (ACU)	
ACS880-307-0330A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0490A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0650A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) Diode Supply Unit (DSU)	
ACS880-307-0980A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Diode Supply Unit (DSU) Auxiliary Control Unit (ACU)	
ACS880-307-0910A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-1210A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-1820A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-307-2430A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-2730A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-3640A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-4560A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-5470A-3	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-0910A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-1210A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-1820A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-2430A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-2730A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-3640A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-4560A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-5470A-5	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-0570A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-0760A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-0820A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-1060A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-1520A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-2130A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-2280A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-3040A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-3800A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-307-4560A-7	ACS880-307 - Diode supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-0420A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	IGBT Supply Unit (ISU) Auxiliary Control Unit (ACU)	
ACS880-207-0580A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	IGBT Supply Unit (ISU) Auxiliary Control Unit (ACU)	
ACS880-207-0810A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU) IGBT Supply Unit (ISU)	
ACS880-207-0400A-5		Control Panels, Displays and Accessories	IGBT Supply Unit (ISU) Auxiliary Control Unit (ACU)	
ACS880-207-0530A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	IGBT Supply Unit (ISU) Auxiliary Control Unit (ACU)	
ACS880-207-0730A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	IGBT Supply Unit (ISU) Auxiliary Control Unit (ACU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-207-2350A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-2120A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-0310A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-0370A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-0540A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1570A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1130A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1330A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1580A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-3110A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-4620A-3	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1040A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1420A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-2800A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-4150A-5	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-0720A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-1050A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-2070A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-3080A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-4100A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-207-5130A-7	ACS880-207 - IGBT supply unit	Control Panels, Displays and Accessories	Auxiliary Control Unit (ACU)	
ACS880-107-0470A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0640A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0760A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0900A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1250A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1480A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1760A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-2210A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-107-2610A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-3450A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-4290A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-5130A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0440A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0590A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0740A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0810A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1150A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1450A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-1580A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-2150A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-2350A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-3110A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-3860A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-4610A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0340A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0410A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0530A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0600A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0800A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1030A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1170A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1540A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-1740A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-2300A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-2860A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-3420A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-3990A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-107-4560A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-5130A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-5700A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0062A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0082A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0100A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0130A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0140A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0190A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0220A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0270A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0011A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0014A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0018A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0025A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0035A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0044A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-004A8-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0050A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0061A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-006A0-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0078A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-008A0-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0094A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0100A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0140A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0170A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0210A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0250A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-107-0300A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0350A-3	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0011A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0014A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0018A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0025A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0030A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0035A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-003A6-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-004A8-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0050A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0061A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-006A0-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0078A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-008A0-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0094A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0110A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0140A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0170A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0200A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0240A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0300A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0340A-5	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Drive Control Unit (DCU) Inverter Unit (INU)	
ACS880-107-0018A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0022A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0027A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0035A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0042A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-0052A-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-107-007A3-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-009A8-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-107-014A2-7	ACS880-107 - Inverter unit	Control Panels, Displays and Accessories	Inverter Unit (INU) Drive Control Unit (DCU)	
ACS880-01-442A-3	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-441A-5	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
PVS980-58-1818kVA-I	PVS980			Boards, Control Units, Power Supplies
PVS980-58-1909kVA-I	PVS980			Boards, Control Units, Power Supplies
PVS980-58-2000kVA-K	PVS980			Boards, Control Units, Power Supplies
ACS880-01-364A-3	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-303A-5	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-362A-5	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-01-415A-5	ACS880-01 - Wall-mounted single drive	Control Panels, Displays and Accessories		
ACS880-04F-504A-3	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-584A-3	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-649A-3	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-725A-3	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-820A-3	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-880A-3	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-459A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-502A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-582A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-634A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-715A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-820A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-880A-5	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-329A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-369A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-429A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-470A-7	ACS880-04F	Control Panels, Displays and Accessories		

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-04F-522A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-590A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-650A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-04F-721A-7	ACS880-04F	Control Panels, Displays and Accessories		
ACS880-M04-04-03A0-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-03A6-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-04A8-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-06A0-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-08A0-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-010A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-014A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-018A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-025A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-030A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-035A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-044A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-050A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-061A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-078A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-094A-2	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-03A0-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-03A6-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-04A8-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-06A0-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-08A0-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-010A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-014A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-018A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-025A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		

Product	Category	Drive Part Category	Drive Section	Inverter Part Category
ACS880-M04-04-030A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-035A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-044A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-050A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-061A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-078A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
ACS880-M04-04-094A-5	ACS880-M04 - Machinery Drive	Control Panels, Displays and Accessories		
PVS980-58-1909kVA-J	PVS980			Boards, Control Units, Power Supplies
PVS980-58-2091kVA-L	PVS980			Boards, Control Units, Power Supplies

—

Categories

Drives → Drive options → User interface options

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Drive options → User interface options

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Drive options → User interface options

Drives → Low voltage AC drives → Industrial drives → ACS880 drive modules → ACS880-04F

Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-107 - Inverter unit

Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-1607 - DC-DC converter (DDC)

Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-207 - IGBT supply unit

Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-307 - Diode supply unit

Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-607 - Brake unit

Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-907 - Regenerative rectifier unit

Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-01 - Wall-mounted single drive

Drives → Low voltage AC drives → Machinery drives → ACS880-M04 - Machinery Drive

Power Converters and Inverters → Solar Inverters → Central Inverters → PVS980

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 drive modules → ACS880-04F

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 drive modules → ACS880-04F

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-107 - Inverter unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-1607 - DC-DC converter (DDC)

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-207 - IGBT supply unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-207 - IGBT supply unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-307 - Diode supply unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-307 - Diode supply unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-607 - Brake unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-907 - Regenerative rectifier unit

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-01 - Wall-mounted single drive

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-01 - Wall-mounted single drive

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Machinery drives → ACS880-M04 - Machinery Drive

Water Utility Solutions → Desalination Plant → Electrical → Drive systems → Drives → Low voltage AC drives → Machinery drives → ACS880-M04 - Machinery Drive