Fitting Instructions WA300 and WA500 Wall/Ground anchors



Pack includes

1 x WA300 or WA500 anchor
2 x M10 x 70mm long CSK Bolts
2 x M10 bolt shields
2 x 6.35 diameter ball bearings.

Please note: The wall/ground anchor must be secured into good solid concrete or brick surfaces

1. Using the WA300/WA500 as a template, drill through the two holes with a 12mm diameter concrete drill to a depth of 10mm.

2. Remove the WA300/WA500 and then re-drill the two holes with a 16mm diameter concrete drill to a depth of 90mm.

3. Drop the bolt shields into the drilled holes, place the WA300/WA500 over the holes and put the bolts through the WA300/WA500 and tighten the bolts evenly to a torque of 20NM.

4. Once the unit has been fitted satisfactorily it is recommended for total security the two steel balls are hammered into the top of the socket heads.

Henry Squire & Sons Limited
Hilton Cross Business Park, Cannock Road, Featherstone, Wolverhampton, WV10 7QZ
Tel: 01902 308050 Fax: 01902 308051
E-Mail: info@henry-squire.co.uk Website: www.squirelocks.co.uk